




Assembly Instruction for

RECTANGULAR DINING TABLE

D-1710-5-DT2/ D-1710-6-DT2 / D-1710-8-DT2

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
NO.	PART DESC	CODE.	Q'TY
A	TABLE TOP		1
B	TABLE LEG FRAME		2
C	TABLE CENTER STRETCHER		1
D	TABLE CONNECTED PANEL		2


HARDWARE LIST				
NO.	HARDWARE DESC	CODE.	Q'TY	
1		BOLT (5/16" x 1-3/8")	PD-1710-DT2HW	18
2		SPRING WASHER (5/16")		18
3		FLAT WASHER (5/16" x 3/4")		18
4		ALLEN KEY(M5)		1
5		THREADED PINS (5/16" x 3")		2
6		HALF MOON (5/16")		2
7		HEX NUT (5/16" x 1/2")		2
8		WRENCH (1/2" x 3-1/2")		1

⚠ Only tighten all bolts when all bolts aligned with bolt inserts.

STEP : 1




STEP : 2



Assembly Instruction for
RECTANGULAR DINING TABLE
D-1710-6-DT2 / D-1710-8-DT2/D-1710-5-DT2

STEP : 3



COMPLETED

