


# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

360147 **Sofa bed**  **ITEM:** 360147



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

1. Remove hardware from box and sort by size.

Please check to see that all hardware and parts are present prior to start of assembly.
Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


30 MINUTES


#### PARTS IDENTIFICATION


Α	SOFA	1PC	В	PILLOW	2PCS
С	ARM L	1PC	D	ARM R	1PC
Е	LEG	4PCS			

#### HARDWARE IDENTIFICATION


3 WASHER **BOLT** 2 ALLEN WRENCH 1PC 8PCS 8PCS (M8X2") (8M)(5#)







#### STEP 2





# **ITEM**: 360147

#### **ASSEMBLY INSTRUCTIONS**










## STEP 4




## STEP 5















**ITEM:** 360147

### **ASSEMBLY INSTRUCTIONS**

# COASTER<sup>®</sup>

## **PRODUCT DIMENSION**





Note: Dimension tolerance ±5%