

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / NO D'ARTICLE / ARTICULO NO. : P375302

DESCRIPTION/ LA DESCRIPTION / DESCRIPCIÓN : BUFFET / BUFSET / APARADOR

A WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!









A

x1 Buffet
x1 Buffet
x1 Aparador




B

x2 Front leg ★
x2 Patte avant
x2 Pata delantera



C

x1 Back leg (left) ★
x1 Patte arrière (gauche)
x1 Pata trasera (izquierda)



D

x1 Back leg (right) ★
x1 Patte arrière (droite)
x1 Pata trasera (derecha)



E

x1 Center leg ★
x1 Pattes centrales
x1 Patas centrales




F

x8 Flat Washer Ø5/16"x19x2mm ★
x8 Rondelle plate Ø5/16"x19x2mm
x8 Arandela plana Ø5/16"x19x2mm




G

x8 Lock washer Ø5/16" ★
x8 Rondelle de blocage Ø5/16"
x8 Arandela de Seguridad Ø5/16"



H

x8 Allen bolt Ø5/16"x51mm ★
x8 Vis à tête creuse hexagonale Ø5/16"x51mm
x8 Perno Allen Ø5/16"x51mm



I

x1 Allen key 5mm
x1 Clé hexagonale 5mm
x1 Llave Allen 5mm



J

x1 Furniture Tipping Restraint ★
x1 Systeme antibasculement
x1 Control para evitar vultcos


★ Replaceable Part

ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE

ITEM NO. / NO D'ARTICLE/ ARTICULO NO. : P375302

DESCRIPTION/ LA DESCRIPTION /DESCRIPCIÓN : BUFETET / BUFETET / APARADOR




⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:


- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



★ Replaceable Part

REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE
ITEM NO. / NO D'ARTICLE/ ARTICULO NO. : P375302
DESCRIPTION/ LA DESCRIPTION /DESCRIPCION : BUFET / BUFET / APARADOR








A WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



- | | | |
|--|--|--|
| 
x2 RP375302-FLEG-FRONT LEG
Jambes
Pernas | 
x1 RP375302-BLEGL-BACK LEG-Left
Jambes
Pernas | 
x1 RP375302-BLEGR-BACK LEG-Right
Jambes
Pernas |
| 
x1 RP375302-CE-Center Leg
Support central
Soporte para la pata central | 
x4 RP375302-PULL-Pull with Screw
Pognée + vis
Tirador + Tornillo | 
x1 COMGLIDE-12-45-Drawer Glide
Glissière
Carri de deslizamiento |
| | 
x1 RP375302-TRAY - Jewelry tray
Plateau de bijoux
Bandeja de joyas | |

- | | | | |
|--|---|--|--|
| 
x2 RP375302-SHELF-Wood Shelf
Étagère
Repisa/ Estante | 
x8 RP375302-PIN- Shelf pin
Supports Pour
Tablette Soporte De Las Repisas | 
x8 RP375302-HINGE-Door Hinge
Charnière de porte
Bisagra de la puerta | 
x8 RP375302-CATCH-Door Catch
Catch de aimant
Captura de imán |
| 
x2 RC-WH-NAL - White Plastic Nail
Clou en plastique
Clavo de plástico | 
x3 RC-FG-WHITE-White Leveler
Patin réglable
Nivelador | 
x1RP375302-HWKT- Hardware Kit
Liste des pièces de quincaillerie
Lista del kit de materiales | 
x1 RC-ANTI-TIP - Anti-tipping Restraint
Système antitascèlement
Control para evitar vlticos |

★ Replaceable Part

Protect Your Wood or Laminate Flooring

* This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floor without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.

** Replaceable Part*