

KINCAID

## WAGNER FOUR DOOR CONSOLE

ABODE COLLECTION

ITEM # 269-585







The Wagner Four Door Console is designed to function well in a variety of settings. Shown here as a large entertainment console, it can be used alone or flanked by one - or more - of the Wagner Cabinet for larger spaces. It uses framed, fluted glass on the door fronts to maintain a clean, transitional style. Behind the two middle doors is a single, large open space with one adjustable shelf. There is also an adjustable shelf behind each of the two end doors. And to assist with electronics, there is an electrical outlet integrated into the back of the piece.



Solid Wood - Made using genuine solid wood construction



Electrical Cord Management - Electrical outlets built in for convenience



Mortise & Tenon Joinery

Mortise & Tenon Joinery - Features time-tested mortise & tenon joinery

---

## Dimensions



Height:	34"
---------	-----

Width:	76"
--------	-----

Length:	20"
---------	-----

---

## Care and Cleaning



Care & Cleaning/Care of Finish - Finishes are naturally resistant to minor everyday hazards or accidents, however, some precautions are necessary to maintain the beauty of wood furniture. (1) Dust with soft cloth slightly moistened with water. Always rub in the direction of the wood grain. (2) Do not place beverages directly on furniture. (3) Furniture should not be placed in direct sunlight. (4) Remove any spills or smudges immediately.

---

## Other Details



■ Alder

---