

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

707917 <u>End Table</u>

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

А ТОР



1PC

B LEG

(M10 X 25mm - BLK)



3PCS

HARDWARE IDENTIFICATION

1 BOLT (M6 X 20mm - BLK) 6PCS


2 FLAT WASHER 6PCS

3 ALLEN WRENCH (4mm - BLK)




ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

707918 Coffee Table

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A TOP



1PC

B LEG



3PCS

HARDWARE IDENTIFICATION

1 BOLT (M6 X 20mm - BLK)



6PCS

2 FLAT WASHER (M10 X 25mm - BLK)



6PCS

3 ALLEN WRENCH (4mm - BLK)




1PC




ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%