


(1)x1	(2)x1	(3)x1 (L)x1 (R)
Back Cushion	Seat Cushion	Left-Arm-L, Right-Arm-R
(4)x1	(5)x1	(6)x1
Mechanism	Gas Lift W/ Cover	Base
(7)x5		
Caster		

- (A)*4 M8*22 MECHANISM SCREW
 (B)*8 M6*25 ARM SCREW
 (C)*8 ARM CAP



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

