

ASSEMBLY INSTRUCTIONS

MODEL #

CM5089-TV-60/72

Questions?

GIVE US CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED




Allen Wrench

(Included)



Phillips
Screwdriver

(Not Included)



**2 - People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.

 **Consumer Hotline**
Toll-Free 1-888-980-5122

 **Monday to Friday**
8:30AM- 5:30PM (PST)

 **WEBSITE**
www.foagroup.com

 **E-MAIL**
cs.ec@foagroup.com

    foagroup

 FurnitureOfAmerica

CHECK BEFORE STARTING

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Should we send any replacements?


Are there any irregularities or flaws in the parts? We can send replacements!

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TV STAND

CM5089-TV-60/72




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc



Top Frame

#2 1pc




Right Medium Panel

#3 1pc



Left Medium Panel

#4 1pc



Front Frame

#5 2pcs



Side Back Panel

#6 1pc



Medium Back Panel

#7 1pc




Bottom Panel

#8 2pcs



Support Wood

#9 1pc



Medium Shelf

#10 2pcs



Side Shelf

HARDWARE

#A 1pc



Allen Wrench M4

#B 8pcs



Bolt $\varnothing 1/4"$ X1-1/4"

#C 8pcs



Lock Washer $\varnothing 1/4"$

#D 8pcs



Flat Washer $\varnothing 1/4"$

#E 12pcs



Shelf Support

#F 2pcs



Pull

#G 2pcs



Screw $\varnothing 5/32"$ X1-1/4"

#H 2pcs




Wood Screw $\varnothing 8$ X1"

ASSEMBLY INSTRUCTIONS

1

Unfold front frame (#4).

Part #4 X1pc




2

Attach support woods (#8) to the holes of the bottom panel (#7).

Part #7 X1pc


Part #8 X2pcs



ASSEMBLY INSTRUCTIONS

3

Align and insert bottom panel (#7) to the brackets of the front frame (#4).
Make sure the bottom panel (#7) is in place.




4

Attach right and left panels (#2,3) to the bottom panel and front frames (#7,4).

Part #2 X1pc

Part #3 X1pc




ASSEMBLY INSTRUCTIONS

Slide back panels (#5,6) through the thin lined gaps of the TV-Stand.

5

Part (#5) X2pcs

Part (#6) X1pc



6

Align top frame (#1) to the top of the TV-Stand, then secure from the inside by using bolts (#B) with washers (#C,D).


Part (#1) X2pcs

Hardware (#A) X1pc

Hardware (#B) X8pcs

Hardware (#C) X8pcs

Hardware (#D) X8pcs



ASSEMBLY INSTRUCTIONS


7

Attach shelf supports (#E) to the holes in the TV-Stand, then place shelves (#9,10) to the shelf supports (#E).

Part (#9) X1pc

Part (#10) X2pcs

Hardware (#E) X12pcs




8

Hardware (#F) X2pcs

Hardware (#G) X2pcs

Align and secure knobs (#F) to the doors by using bolts (#G).




ASSEMBLY INSTRUCTIONS

9

If the guest buy pier cabinet, can put the TV stand on the back of the top panel flat iron, secure a wood screw , connect the TV stand and 2 pier cabinets.

Hardware #H X2pcs



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.