




Position ID	Spare part number.	Replacement	Description
0102	00607792		nut and bolt for slide in grid
8401	00562464		Operating/installations instructions Gag
0101	00574633		Pull-Out Rack System
0103	00707217		Adapter für GN-roaster,
0104	00552829		Part not included in this appliance
0105	11023413		Rail-pull out