


**MOE'S**  
home collection

# **ASSEMBLY INSTRUCTIONS.**

SYDNEY DINING TABLE NATURAL

**QO-1027-24**



THANK YOU FOR YOUR PURCHASE !

## PARTS AND HARDWARE.

### PARTS LIST

No.	DESCRIPTION	IMAGE	Q'TY
P1	TOP		1
P2	BASE		1

### HARDWARE LIST

No.	DESCRIPTION	IMAGE	Q'TY
H1	M8x30 BOLT		4
H2	SPRING WASHER (M8X14)		4
H3	FLAT WASHER (M8X16)		4
H4	M4 Allen key		1
H5	Screw (4X30)		6
H6	FLAT WASHER (M6X12)		6
H7	SCREW DRIVER		Not provided


## NOTES.

Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping.



**CAUTION:** The item is heavy, assembly should be performed by two people.

## STEP 1.



Unassemble bolts, washer → Take out Mounting plate  
Note: This number of bolts, washer is used for installation in Step 3.



## STEP 2.



## STEP 3.



ADJUST LEVELER FOR BALANCE