



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

603192
Loveseat

ITEM: **603192**



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts represent prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A SEAT



1PC

B LEFT EAR




1PC

C RIGHT EAR




1PC

D LEFT BACK




1PC

E CONSOLE BACK



1PC

F RIGHT BACK




1PC
1PC


ITEM: **603192**




STEP 1




STEP 2



STEP 3



STEP 4




ITEM: 603192

ASSEMBLY INSTRUCTION




STEP 5





STEP 6

COMPLETE



ITEM: **603192**



Note: Dimension tolerance $\pm 5\%$