

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710137 *End Table*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	ТОР	1PC
В	LEG (WITH LABEL "B")	1PC
С	LEG (WITH LABEL "C")	1PC
D	LEG (WITH LABEL "D")	1PC


HARDWARE IDENTIFICATION

1	BOLT (M8 x 20mm - BLK)	8PCS
2	FLAT WASHER (M10 x 16mm - BLK)	8PCS
3	ALLEN WRENCH (5mm - BLK)	1PC


COASTER*

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2




STEP 3




ASSEMBLY INSTRUCTIONS

COASTER'

STEP 4




STEP 5 COMPLETE









Note: Dimension tolerance ±5%

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

710138 Coffee Table

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	ТОР	1PC
В	LEG (WITH LABEL "B")	1PC
С	LEG (WITH LABEL "C")	1PC
D	LEG (WITH LABEL "D")	1PC


HARDWARE IDENTIFICATION

1	BOLT (M8 x 20mm - BLK)	16PCS
2	FLAT WASHER (M10 x 16mm - BLK)	16PCS
3	ALLEN WRENCH (5mm - BLK)	1PC


COASTER FINE FURNITURE

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2




STEP 3




COASTER

ASSEMBLY INSTRUCTIONS

STEP 4




STEP 5 COMPLETE



凉

COASTERFURNITURE.COM





Note: Dimension tolerance ±5%