


ASSEMBLY INSTRUCTIONS

TITIAN TV STAND MODEL# 86158ATOB-01-KD-U Sears# 15393




Front view

Back view



PARTS IDENTIFICATION

ITEM	DESCRIPTION	QTY
#1	TOP	01
#2	LEFT SIDE	01
#3	RIGHT SIDE	01
#4	SHELF	01
#5	BOTTOM CENTER SUPPORT	01
#6	BOTTOM FRAME	01
#7	BACK PANEL	01
#8	TOP CENTER SUPPORT	01
#9	DRAWER FRONT	02
#10	LEFT DRAWER SIDE	02
#11	RIGHT DRAWER SIDE	02
#12	DRAWER BACK	02
#13	DRAWER BOTTOM	02
#14	RAIL	01





HARDWARE IDENTIFICATION


Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.

ITEM	PICTURE		DESCRIPTION	QTY
A		(Ø4) Not to Scale	LARGE BOLT	02
В		Not to Scale	KNOB	02
С		(Ø8x40mm) Full Size	WOOD DOWEL	02
D		(Ø8x30mm) Full Size	WOOD DOWEL	24
E	(† († († († († († († († († († († († († ((Ø4x25mm) Full Size	SCREW	50
F	(†) (†)/////////////////////////////////	(Ø3x15mm) Full Size	SCREW	19
G		(Ø9mm) Full size	FLAT WASHER	02
н		Not to Scale	STRAP	01
ı		(30mm) Not to Scale	WALL ANCHOR	01

Tools required








IMPORTANT:

- 1. DO NOT TIGHTEN BOLTS COMPLETELY UNTIL ALL BOLTS ARE COMPLETELY LINED UP AND INSERTED INTO HOLES / NUTS.
- 2. DO NOT OVER TIGHTEN SCREWS AND BOLTS TO AVOID STRIPPING.




STEP 3.

knocking the wooden dowels tight by hammer




STEP 4.


knocking the wooden dowels tight by hammer




















STEP 11.



STEP 12.





*** CAUTION *** - This stand is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than the maximum weights indicated may result in instability causing possible injury.

Model: 86158ATOB-01-KD-U Description: TITIAN TV STAND

Distributor/Manufacturer: Linon Home Decor Products,Inc.

Origin: China

