

Figure 1





SECURING THE GRIDDLE:

- 1. First remove the Truss HD Philips Screw as indicated above.
- 2. Lock cart wheels from moving
- 3. With a partner, Place the Griddle on top of the Cart on the mounting hole locations as shown in figure 1.
- 4. Secure Griddle to cart by following the steps listed below:
 - 1) Insert the Washer Space between the griddle bottom face and hex rivnut.
 - First through the Griddle rear panel cutouts, hand-tighten the Bolt (200-0219) with Pressure Washer lock as indicated in the bottom right image.
 - 3) Repeat on opposite side of cart.
 - 4) Once secure, tighten bolts further with adjustable wrench if needed.
 - 5) Continue on next page.

