

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

881571 WRITING DESK

REVISION 0: 04/07/2021

PAGE 1 OF 15

COASTERFURNITURE.COM




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 80 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL	1	PC
В	BOTTOM PANEL	1	PC
С	LEFT PANEL	1	PC
D	LEFT MIDDLE PANEL	1	PC
E	RIGHT MIDDLE PANEL	1	PC
F	RIGHT PANEL	1	PC
	PAGE 2 OF 15	COASTERFURNI	ΓURE.COM

ITEM:881571 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



G	BACK PANEL		1PC
н	LARGE DRAWER FRONT PANEL		1PC
I	DRAWER RIGHT PANEL		3PCS
J	DRAWER LEFT PANEL		3PCS
К	LARGE DRAWER BACK PANEL		1PC
L	LARGE DRAWER BOTTOM PANEL		1PC
М	SMALL DRAWER FRONT PANEL		2PCS
	PAGE 3 OF 15	COASTERFU	JRNITURE.COM

ITEM:881571 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



N	SMALL DRAWER BACK PANEL	2PCS
0	SMALL DRAWER BOTTOM PANEL	2PCS
Р	LEFT FRONT FRAME	1PC
Q	RIGHT FRONT FRAME	1PC
R	LEFT BACK FRAME	1PC
S	RIGHT BACK FRAME	1PC
Т	SHORT CROSSBAR	4PCS



U	SUPPORT CROSSBAR	2PCS

V LONG CROSSBAR 1PC

A1 BACK FRAME 1PC

A2 SLIDE RAIL 6PCS




		_	_		-		_	_	_	_	_	_	_	_			
ŀ	4/	4	R	D	W	/A	RE	E 10)E	ΞΙ	N	ΤI	F	IC/	Α Τ	101	V


1	LONG BOLT (ø1/4" x 50mm SR)	6	9PCS	8	CAM LOCK (ø15mm)	€®	14PCS
2	MEDIUM BOLT (Ø1/4" x 38mm SR)		8PCS	9	WOOD DOWEL (8 x 30mm)		14PCS
3	SHORT BOLT (Ø1/4" x 13mm SR)	~ @	28PCS	10	LEVELER (1/4" x 12mm BLK)		8PCS
4	LONG SCREW (4 x 32mm)		24PCS	11	LARGE CAP (20 x 40mm)		8PCS
5	SLIDE RAIL SCREW (3.5 x 12mm)	•	18PCS	12	SMALL CAP (20 x 20mm)		2PCS
6	SMALL BOLT (ø5/32" x 12mm)	₩	6PCS	13	GLUE		1PC
7	CAM BOLT (38mm)		14PCS	14	ALLEN WRENCH (4mm)		1PC



STEP 1


Do not tighten until each step is completed or instructed.









STEP 3









STEP 5







ASSEMBLY INSTRUCTIONS STEP 7














STEP 11








STEP 13



STEP 14




PAGE 13 OF 15

COASTERFURNITURE.COM




COASTERFURNITURE.COM

STEP 15



STEP 16 COMPLETE




PAGE 14 OF 15



Product Size: 1574 X 597 X 787 H (MM)

Product Size: 62" X 23.5" X 31"



Note: Dimension tolerance ±5%