


## **ASSEMBLY INSTRUCTIONS**

## I-MIX-C019

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



|--|

HARDWARE	
DESCRIPTION	PCS
ALLEN KEY 3/16	1
HEX SOCKET BUTTON HEAD 5/16 × 1 1/4"	4
LOCK WASHER 5/16	4
WASHER 5/16	4



## **INSTRUCTIONS**

- WITH HELP, TURN FACE DOWN THE TOP IN A CLEAN SURFACE. 1.
- PLACE THE BASE OVER THE THE TOP, MATCHING THE SCREWS TO THE PRE-DRILLED HOLES. 2.
- 3. ASK FOR HELP TO TURN THE TABLE IN TO THE RIGHT POSITION.