

Assembly Instruction For

CHEST
B.12010.CH


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
NO.	PART DESC	CODE	Q'TY
1	CHEST	PB.12010. CH	1
2	LEG (i)	PB.12010. CGLEG1	2
3	LEG (ii)	PB.12010. CGLEG2	2

HARDWARE LIST				
NO.	HARDWARE DESC		CODE	Q'TY
A		JCBC SCREW (M6 x 40MM)	PB.12010. CGHW	4
B		SPRING WASHER (M6 x 13MM)		4
C		FLAT WASHER (M6 x 19MM)		4
D		WOOD DOWEL (M6 x 30MM)		4
E		M4 ALLEN KEY (65MM)		1
F		TIPPING RESTRAINT	PB.12010. ATK	1


STEP 1



Assembly Instruction For

CHEST
B.12010.CH

STEP 2



STEP 3 COMPLETED

