

### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

723777 END TABLE

REVISION 0: 05/05/2021 REVISION 1: 12/06/2022

PAGE 1 OF 11




#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




# ITEM:723777 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



E BOTTOM PANEL



F DRAWER FRONT PANEL



G DRAWER LEFT PANEL



1PC

H DRAWER RIGHT PANEL



1PC

I DRAWER BACK PANEL



1PC

PAGE 3 OF 11


# ITEM:723777 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



J DRAWER BOTTOM PANEL




K HANDLE



1PC

L SIDE FRAME




2PCS

M TOP CROSSBAR



2PCS

N BOTTOM CROSSBAR




2PCS



#### HARDWARE IDENTIFICATION


1	CAM BOLT (45MM)	02 <b>JW</b>	14PCS	6	SHORT SCREW (5/32" x22mm)		2PCS
2	CAM-LOCK (ø15MM)		14PCS	7	SHORT BOLT (1/4" x 12mm)	<b>(a)</b>	20PCS
3	WOOD DOWEL (8 x 35mm)		16PCS	8	CAP (25 x 25mm)		4PCS
4	LONG SCREW (8 x 38mm)	<b>ONTOTAL</b>	4PCS	9	GLUE		1PC
5	SMALL BOLT (5/32" x12mm)	•	2PCS	10	ALLEN WRENCH (4mm)		1PC

STEP 1 Do not tighten until each step is completed or instructed.







STEP 2




#### STEP 3







#### STEP 5




PAGE 7 OF 11




COASTERFURNITURE.COM

STEP 6




#### STEP 7




PAGE 8 OF 11




STEP 8








STEP 10



#### STEP 11 COMPLETE





PAGE 10 OF 11



Product Size : 597 X 603 X 616 H (MM)

Product Size: 23.5" X 23.75" X 24.25"






Note: Dimension tolerance ±5%



### ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

### 723778 LIFT TOP COFFEE TABLE

REVISION 0: 05/05/2021 REVISION 1: 12/06/2022

PAGE 1 OF 4



#### ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES


#### PARTS IDENTIFICATION






STEP 1

Do not tighten until each step is completed or instructed.



#### STEP 2



COMPLETE





COASTERFURNITURE.COM

PAGE 3 OF 4



Product Size : 1200 X 597 X 508 H (MM)
Product Size : 47.25" X 23.5" X 20"





Note: Dimension tolerance ±5%