





ITEM NAME/NOM D'ITEM: JAMES DINING CHAIR
ITEM#/NO.ITEM:109013

PART LIST/LISTE DES PIÈCES


(1)	(2)	(3)	(4)	(5)
				A.  M6x18 x4 B.  M6x35 x4 C.  x8 D.  x1
x1	x1	x2	x1	

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I




II



III



IIII



For missing parts or damaged parts,please call/
Pour pièce manquante ou endommagée, veuillez appeler

USA:1-866-798-6663
Canada:514-382-6661