




# ASSEMBLY INSTRUCTION

## 2756 - COCKRELL COUNTER HEIGHT BENCH

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may come loose inside the carton during shipment. Identify and count all parts.


NOTE: Assemble the bench on a flat & soft surface. do not tighten all the screws until the bench has been put a flat /hard surface adjust & level all the legs so that they do not wobble. once adjusted then tighten all the screws.

NOTE: Periodically check to ensure that all connectors (bolts, screw, etc.) are tight.


| PARTS LIST |                                                                                                      |     |
|------------|------------------------------------------------------------------------------------------------------|-----|
| NO         | DESCRIPTION                                                                                          | QTY |
| 1          | CUSHION SEAT        | 1   |
| 2          | LEG ( LEFT )        | 2   |
| 3          | LEG ( RIGHT )       | 2   |
| 4          | SIDE BAR ( SHORT )  | 2   |
| 5          | SIDE BAR ( LONG )   | 2   |

| HARDWARE LIST |                                                                                                                    |     |
|---------------|--------------------------------------------------------------------------------------------------------------------|-----|
| NO            | DESCRIPTION                                                                                                        | QTY |
| A             |  JCBC SCREW (NYLOK)<br>M6 x 60MM | 8   |
| B             |  ALLEN KEY M4                    | 1   |
| C             |  PAN HEAD #8 x 32MM              | 8   |


### STEP 1




### STEP 2



### STEP 3



### STEP 4



NOTE: To ensure bench durable and long lasting, please check entire bench part whether it's in safe and ordinary conditions. The hardware is located in the packing items.