


# B E R N H A R D T

---


## I N T E R I O R S

### KELSEY SECTIONAL




ARMLESS CHAIR N9630

W 30 | D 40 | H 35.50 in.  
SH 19 | SD 24 in.




CORNER CHAIR N9632

W 40 | D 40 | H 35.50 in.  
SH 19 | SD 24 in.




LEFT ARM CHAISE N9638

W 34.50 | D 74 | H 35.50 in.  
SH 19 | AH 24.50 | SD 58.50 in.




RIGHT ARM CHAISE N9637

W 34.50 | D 74 | H 35.50 in.  
SH 19 | AH 24.50 | SD 58.50 in.




LEFT ARM LOVESEAT N9642

W 64.50 | D 40 | H 35.50 in.  
SH 19 | AH 24.50 | SD 24 in.




RIGHT ARM LOVESEAT N9641

W 64.50 | D 40 | H 35.50 in.  
SH 19 | AH 24.50 | SD 24 in.




ARMLESS LOVESEAT N9640

W 60 | D 40 | H 35.50 in.  
SH 19 | SD 24 in.



LEFT ARM RETURN SOFA N9694

W 105 | D 40 | H 35.50 in.  
SH 19 | AH 24.50 | SD 24 in.



RIGHT ARM RETURN SOFA N9693

W 105 | D 40 | H 35.50 in.  
SH 19 | AH 24.50 | SD 24 in.