

Assembly Instructions

BAR SCROLL BACK STOOL W/ WOOD SEAT


DST100BSCSBTW

- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 3. Please do not over tighten screws or bolts.
 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST FOR BAR SCROLL BACK STOOL			
No.	PART DESC	CODE.	Q'TY
A	BAR SCROLL BACK STOOL W/ WOOD SEATL - BACK FRAME	PDST100BSCSBBFR	1
B	BAR SCROLL BACK STOOL W/ WOOD SEAT - SEAT FRAME	PDST100BSCSBSEA	1
C	BAR SCROLL BACK STOOL W/ WOOD SEAT - L&R FRONT LEG SET	PDST100BSCSBLEG	2
D	BAR SCROLL BACK STOOL W/ WOOD SEAT - SIDE STRETCHER LEFT / RIGHT	PDST100BSCSBSTR1	2
E	BAR SCROLL BACK STOOL W/ WOOD SEAT - FRONT STRETCHER FRONT	PDST100BSCSBSTR2	1

HARDWARE LIST PACKED INSIDE BOX			
No.	HARDWARE DESC	CODE.	Q'TY
1	 ALLEN BOLT (1/4" x 40mm)	PDST100BSCSBHW	2
2	 ALLEN BOLT (1/4" x 60mm)		4
3	 ALLEN BOLT (1/4" x 75mm)		4
4	 SPRING WASHER (1/4")		10
5	 FLAT WASHER (1/4")		10
6	 SCREWS (M4x38MM)		6
7	 ALLEN KEY (M4)		1

STEP:1



STEP:2



COMPLETED

