

HOOKER® ASSEMBLY INSTRUCTION

Step 2


Item: 5971-10458-99 Bristowe Writing Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process:


HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
Α		NUT	Φ5/16"×12	8pcs
В	0	FLAT WASHER	Φ5/16"×19×2	8pcs
С	٥	LOCK WASHER	Φ5/16"×12×3	8pcs
D	2	WRENCH	12mm	1pc



Press the left side plastic up, and press the right side plastic down, then pull out the drawer.





Adjust levelers if needed, to level case on uneven floor