


Components and Hardware List

44451 Round Ped Dining Table-Top



A

1pc.

44458 Round Ped Dining Table-Base



B

1pc.

Allen Wrench 5mm

Ø5/16-18 x 1-1/2 Long Bolt

Lock washer Ø5/16" x Ø12 x 3mm

Flat washer Ø5/16" x Ø19 x 2mm



C

1pc.



D

4pcs.




E

4pcs.



F

4pcs.




44451 Round Ped Dining Tbl-Top
44458 Round Ped Dining Tbl-Base


Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

Place the Top upside down on a soft surface.

1. Place the Table Base on the Top and attach using the Bolts (D), Lock Washers (E) and Flat Washers (F). Tighten with the Allen Wrench (C).
2. Set the assembled Table upright.



Step 2



Complete

There are levelers installed underneath the Base which can be adjusted to compensate for uneven floors, if needed.