

## **ASSEMBLY INSTRUCTION**


ITEM: 6005-10458-85 Writing Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

## HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'ty	PARTS LIST			
А	0	FLAT WASHER	ø5/16"	12pcs	NO	DRAWING	DESCRIPTION	Q'TY
В	C	LOCK WASHER	ø5/16"	12pcs	1		LEGS	4
С		BOLT	ø5/16"*30mm	8pcs				
D		ALLEN WRENCH	73*29*5mm	1pc	2		TOP	1
E		BOLT	ø5/16"*100mm	4ncs	3	<b>©</b>	BUN FOOT	4
	- Harman Managaran		10,10	трсз		<u>.</u>	BOTTOM FDAME	
F	Image: Control of the	Anti — Tip Kit		1рс	4	\ \frac{1}{2}	BOTTOM FRAME	1



Step 2: Attach bottom frame and bun foots to legs by using Allen wrench & bolt & lock washer & flat washer



## **ASSEMBLY INSTRUCTION**

ITEM: 6005-10458-85 Writing Desk

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

