

Skype™ for Samsung TV

Getting started with Skype	2
To sign in with an existing account	3
To sign in using Face recognition	4
Face recognition	5
Creating new account	6
Screen display	7
Adding a contact	8
To call a contact	9
Receiving	10
History	11
Skype Options	12
Voice and Motion Control	13

* Images and colors can be changed without prior notice.

Getting started with Skype

Make calls and video calls with Skype on your TV.



Make possible by SMART HUB - bringing useful and entertaining features directly from the web to your TV.

NOTE

- Connect your SAMSUNG webcam directly to the TV, not through a USB hub.
- If the webcam isn't working properly, turn the TV off then on again, and relaunch Skype.
- Skype is disabled when the TV is turned off.
- Voice quality may be affected in a noisy environment.
- Using a wireless network can degrade call quality.
- Use of the Skype software is subject to the [Skype End User License Agreement \(skype.com/legal/eula\)](http://skype.com/legal/eula), [Skype Terms of Service \(skype.com/legal/tos\)](http://skype.com/legal/tos) and the [Skype Privacy Policy \(skype.com/legal/privacy/general\)](http://skype.com/legal/privacy/general).
- If Skype is deleted, saved information (History and Options) is deleted.
- For help using Skype, visit skype.com
- You need to configure your network before using Skype on your TV. See instructions in this manual.
- The ring bell rings when someone calls to you while you watch the TV or operate the Skype application.
- To use Skype you need the TV camera. Please buy the TV camera of the SAMSUNG if you don't have the TV a built-in camera.
- TV camera launched in 2010 and the SAMSUNG TV launched in 2012 are incompatible.
- Only Skype version 4.2 or greater is supported on Windows-based PCs.
- Only Skype version 5.0 or greater is supported on Macintosh PCs.
- Not supported on Linux-based PCs.

To sign in with an existing account

When running Skype on your TV for the first time, enter your **Skype Name** and **Password** or **Create Account**. If you can't login, check the network connection.




1 Press the **Sign In**.



2 Enter your **Skype Name** and **Password**.

3 Press the **Sign In**.



Use the keypad to enter the **Skype Name** and **Password**.

To sign in using Face recognition

- You can Sign in Skype using **Face recognition** on TV which supports SMART Interaction (**Voice and Motion Control**).

⚠ In order for Face recognition to function, a thumbnail image of your face will be stored in your TV for logging-in purposes.

⚠ Logging into the Skype using Face recognition does not provide as high a level of security as logging in with an ID and password.




1 Press the **Face Recognition Mode**.

2 The TV starts Face recognition.

- Turn your face towards the TV with your face level with the camera. The TV will recognize your face automatically.




Face recognition




1 Select **Settings** → **Account Manager** → **Face recognition**.

2 The **Face recognition** screen appears.

- Make sure that your face is in the center of the screen.
- Wait until the rectangle in the center of the screen turns green.



Creating new account



1 Press **Create Account**.



2 Enter **Create Skype Name** and **Password**.

3 Enter **Full Name** and **E-mail**.



4 Select **Accept**.

Select one of the terms to see more information.




Screen display

The screenshot shows the Skype application interface. At the top left, there is a 'Skype Credit' indicator. The main header displays the 'skype' logo and the user's name 'samsung tv' with a dropdown arrow and a profile picture icon. Below the header, a contact list is shown, with the first contact being 'Echo / Sound Test Service'. This contact has three buttons: 'Video Call', 'Voice Call', and 'Chat'. On the left side, there is a vertical menu with icons and labels for 'Contacts', 'Chat', 'History', 'Call phones', and 'Settings'. At the bottom right, there are three buttons: 'Sign Out', 'Add a Contact', and 'Return'. The interface is annotated with several callouts:

- Skype Credit**: Points to the 'Skype Credit: 0' indicator at the top left.
- Your contact list. You can select Video call, Voice call or Chat mode.**: Points to the contact list area.
- Your Skype Name, online status, mood message and profile picture.**: Points to the 'samsung tv' header area.
- Select from the menu items Contact, Chat, History, Call phones and Settings. From the menu item press ENTER and scroll to the desired option.**: Points to the left-hand menu.
- Sign out: Select to Sign out.**: Points to the 'Sign Out' button at the bottom right.
- Add a Contact: Add a Skype contact or a phone number.**: Points to the 'Add a Contact' button at the bottom right.
- Return / End Call: Returns to the previous menu. / End the skype application with the call.**: Points to the 'Return' button at the bottom right.


Adding a contact




1 **C** Press **Add a Contact**.

2 Select one.


- **Add a Skype contact** : Enter the person's Skype name, full name or e-mail.
- **Add a phone number** : Enter the name and phone number.



To call a contact



1 Press **Video Call** or **Voice Call**.



- The illustration of the manual may vary from the actual shape partially.



Video Call



Voice Call

Receiving

When in a video or voice call.



Rejects Call.

Video Call

Voice Call



- If a conference call comes in, the Video option is disabled.

-  **End Call**: Hang up the call.
- **Stop Video**: Turns the camera off.
- **Mic. Vol.:** Adjusts the microphone volume.
- **Hold / Resume**: Hold/ Resume the call.
 - ☞ A Skype contact will see a notification message when they are put on hold.
- **Start Video**: Switches to a video call.

-  **(Full Screen)**: Switch to full screen.
-  **(Contact list)**: Displays the contact list.

History

Shows the history of calls you've made, listed from most recent to oldest, top to bottom respectively.



Each call has an icon next to it.

Icons	Meaning
	Incoming call
	Outgoing call
	Missed call
	Incoming voicemail
	Missed voicemail
	Incoming conference call
	Missed conference call

- **View Profile:** View the selected contact's profile.
 - **Send Voicemail:** Send a voicemail message to the selected contact.
 - **Add to Contacts:** Add this person as a contact. This option is available when you don't have this person saved in your Contact list.
 - **Block:** Block this person from contacting you.
 - **Delete This Item:** Remove this item from your History.
 - **Sign Out:** Signs out.
- History can be limited by memory capacity.
- The time set on the TV is applied to the History.

Skype Options



1 Select **Settings** → **Skype Options**.

2 Change the each option(s).

- **General settings:** Select whether you want Skype to launch automatically when you turn on the TV.
- **Video settings:** Adjust the privacy settings for video. Choose who you will receive video from by selecting **Anyone**, **Only people in my Contact list** or **No one**.
- **Privacy Settings:** Choose who you will receive calls from. Select **Allow anyone to contact me** or **Only allow people in my Contact list**.
- **Blocked Users:** If you don't want to hear from someone, block them by entering their Skype Name or phone number. Any blocked persons will be listed in this window. You can also block a person in the Contact and History lists by selecting the **TOOLS** button.
- **Call forwarding (diverting calls):** To forward calls from your Skype account when you're not on Skype, add the phone numbers you want calls directed to. Select the country and enter the number with the area code. Enter the divert time to specify the delay before the call is diverted. You need to buy Skype Credit from skype.com to use this feature.
- **Voicemail:** This feature allows people to leave audio messages when you are away. You can listen to the messages wherever you are signed into Skype. For more information or to get voicemail, go to skype.com and click on Account.
- **About Skype:** View the Skype copyright information.

Voice and Motion Control

- You can call or manipulate in Skype using **Voice and Motion Control** on TV which supports SMART Interaction (**Voice and Motion Control**).
- You can't use **Voice Control** function When in a call.
- **Voice Control** function can be affected recognition by difficult to pronounce name such as including special characters or simple letters of the alphabet, numbers. You can change it by using **Rename**.
- For more detailed information about Smart Interaction, see "Smart Interaction" in e-Manual or User manual.



1

Say "**Hi TV(Trigger Words)**", and then say the name of the person you want to call.



2

Say one.

3

Say **Video Call** or **Voice Call** that will start.

