


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



PAGE 1 OF 12



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 460593 (B1)


12PCS 4PCS
4PCS
16PCS
44PCS
36PCS
30PCS
4PCS
4PCS
1PC


NOTE:

Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


PAGE 3 OF 11

















STEP 11





PAGE 9 OF 11



SIZE OF MATTRESS

The length and width of the bunk mattress are as follow :

Upper bunk Lower bunk <u>Length</u> 74" - 75" 74" - 75" Width 37 1/2" - 38 1/2" 53" - 54" Thickness 6" Maximum 11" Maximum

Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.




- 1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.
- 2. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.
- 3. Surface of mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
- 4. Do not allow children under 6 years of age to use the upper bunk.
- 5. Prohibit more than one person on upper bunk.
- 6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
- 8. Always use the ladder for entering and leaving the upper bunk.
- 9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 10. Use of a night light may provide added safety precaution for a child using the upper bunk.
- 11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- 12. The use of water or sleep flotation mattresses is prohibited.
- 13. Keep these instructions for future reference.


STRANGULATION HAZARD

14. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to hooks, belts and jump ropes.

REPLACEMENT PART :


Replacement part, including additional guardrails may be obtained from any COASTER Furniture Dealer.







ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 01/08/2025

PAGE 1 OF 11



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 460593(B1)

1	LONG BOLT (M6 x 70mm - BLK)		32PCS
2	MEDIUM BOLT (M6 x 30mm - BLK)		12PCS
3	SHORT BOLT (M6 x 16mm - BLK)		4PCS
4	HEX HEAD SCREW (M6 x 28mm - BLK)	~~~~~~ @	16PCS
5	FLAT HEAD SCREW (4.0 x 28mm - BLK)		44PCS
6	WOOD DOWEL (Ø10 x 30mm)		34PCS
7	BARREL NUT (M6 x 13mm - RBW)	×.	32PCS
8	METAL PIN (Ø9.5 x 127mm - RBW)	0	4PCS
9	NUT (M6 - BLK)		4PCS
10	ALLEN WRENCH (M4 - BLK)		1PC

NOTE:


Philips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 11































STEP 11



STEP 12 COMPLETE







SIZE OF MATTRESS

The length and width of the bunk mattress are as follow :

Upper bunk Lower bunk <u>Length</u> 74" - 75" 74" - 75" Width 37 1/2" - 38 1/2" 53" - 54" Thickness 6" Maximum 8" - 9"

Ensure thickness of mattress does not exceed 6" and there must be at least 5" from mattress sleeping surface to top edge of guardrail.



- 1. Follow the information on the warnings appearing on the upper bunk end structure and on the carton. Do not remove warning label from bed.
- 2. Always use the recommended size mattress or mattress support, or both, to help prevent the likelihood of entrapment or falls.
- 3. Surface of mattress must be at least 5 in. (127 mm) below the upper edge of guardrails.
- 4. Do not allow children under 6 years of age to use the upper bunk.
- 5. Prohibit more than one person on upper bunk.
- 6. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
- 7. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
- 8. Always use the ladder for entering and leaving the upper bunk.
- 9. Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- 10. Use of a night light may provide added safety precaution for a child using the upper bunk.
- 11. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
- 12. The use of water or sleep flotation mattresses is prohibited.
- 13. Keep these instructions for future reference.

STRANGULATION HAZARD

14. Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to hooks, belts and jump ropes.

REPLACEMENT PART :

Replacement part, including additional guardrails may be obtained from any COASTER Furniture Dealer.

