

Assembly Instruction for
SQUARE COUNTER DINING TABLE
CFC300CTT&CFC700CTB / CFC700CTT&CFC700CTB


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
- 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3. Please do not over tighten screws or bolts.
- 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST			
NO.	PART DESC	CODE	Q'TY
A	SQUARE COUNTER TABLE - MARBLE TOP		1
B	SQUARE COUNTER TABLE - LEG	PCFC700CTBLEG	4

HARDWARE LIST			
NO.	HARDWARE DESC	CODE	Q'TY
1	 HEX NUT	PCFC700CTBHW	8
2	 LOCK WASHER 5/16"		8
3	 FLAT WASHER 5/16"		8
4	 WRENCH		1

STEP 1



COMPLETED

