2-DRAWER NIGHTSTAND WITH USB

B-3460-7-NS2S/B-3460-5-NS2


Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.

4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.






ASSEMBLY INSTRUCTION FOR 5-DRAWER CHEST B-3460-7-CHS/B-3460-5-CH

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.



ASSEMBLY INSTRUCTION FOR 5-DRAWER CHEST B-3460-7-CHS/B-3460-5-CH



ASSEMBLY INSTRUCTION FOR 6-DRAWER DRESSER


B-3460-7-DRS/B-3460-5-DR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.



ASSEMBLY INSTRUCTION FOR 6-DRAWER DRESSER B-3460-7-DRS/B-3460-5-DR



ASSEMBLY INSTRUCTION FOR 6-DRAWER DRESSER & MIRROR B-3460-7-DRS / B-3460-7-MR B-3460-5-DR / B-3460-5-MR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.

4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


| PART LIST FOR MIRROR | | | | | |
|----------------------|---------------|-----------------|------|--|--|
| NO. | PART DESC | CODE | Q'TY | | |
| Α | DRESSER | B-3460-7-DRS | 1 | | |
| В | MIRROR | B-3460-7-MR | 1 | | |
| С | SUPPORT SLATS | PB-3460-MRSLTCT | 2 | | |


Nonly tighten all bolts when all bolts aligned with bolt inserts

STEP 1

| | HARDWARE LIST FOR MIRROR | | | | | | |
|-----|---|----------------------|------|------|--|--|--|
| NO. | | HARDWARE DESC | CODE | Q'TY | | | |
| 1 | Image: Second system FLAT WASHER (1/4"x 5/8") | | | 8 | | | |
| 2 | 0 | SPRING WASHER (1/4") | | 8 | | | |
| 3 | BOLT (1/4" x 1 3/8") | | 8 | | | | |
| 4 | ALLEN KEY(4mm) | | | | | | |







KING BED WITH LIGHT AND USB B-3460-7/-5-KHFL/ B-3460-7/-5-QKR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.


3. Please do not over tighten screws or bolts.


| | PART LIST FOR KING BED | | | | | |
|---|--------------------------|-------------------|------|--|--|--|
| NO. | PART DESC | CODE | Q'TY | | | |
| Α | HEADBOARD | B-3460-7-KHFL | 1 | | | |
| В | HEADBOARD LEG - LEFT | PB-3460-7-HBLEGCT | 1 | | | |
| С | HEADBOARD LEG - RIGHT | PB-3460-7-HBLEGCT | 1 | | | |
| D | STRETCHER | PB-3460-7-KHSTRCT | 1 | | | |
| Е | FOOT BOARD | B-3460-7-KHFL | 1 | | | |
| F | KING/QUEEN BED SIDE RAIL | B-3460-7-QKR | 2 | | | |
| G | SUPPORT LEG WITH LEVELER | PB-3460-BDSPLCT | 8 | | | |
| н | SLAT PB-3460-KBSLTCT | | 4 | | | |
| Only tighten all bolts when all bolts aligned with bolt inserts | | | | | | |

| | | HARDWARE LIST FOR KING | BED | |
|------|--------------|---------------------------|-----------------------|------|
| NO. | | HARDWARE DESC | CODE | Q'TY |
| 1 | 97 | JCBB BOLT (M8 x 1-9/16") | | 10 |
| 2 | 0 | SPRING WASHER (M8 x 5/8") | | 10 |
| 3 | 0 | FLAT WASHER (M8) | РВ-3460-КВНWCT | 10 |
| 4 | Paramanan an | CSK SCREW (M4 x1 3/16") | | 8 |
| 5 | | ALLEN KEY (M5) | | 1 |
| 6 | 0 | JCBC (M6 x2 3/4 ") | | 4 |
| 7 | 0 | SPRING WASHER (M6 x 3/8") | | 4 |
| 8 | 0 | FLAT WASHER (M6 x 1/2") | | 4 |
| 9 | 9 | NUT M6 PB-3460-SHADCT | | 4 |
| 10 | - | ALLEN KEY M4 | | 1 |
| 11 | ¢. | SHADE | | 2 |
| 12 | | BULB | PB-3460-BULBCT | 2 |
| 13 | Â | POWER CABLE | | 1 |
| 14 | Ì | Y-CABLE | Y-CABLE PB-3460-CABCT | |
| 15 | | USB PORT PB-3460-USB2 | | 1 |
| HARD | WARE LOC | ATED IN LEG BOX | | |



KING BED WITH LIGHT AND USB B-3460-7/-5-KHFL/ B-3460-7/-5-QKR





QUEEN BED WITH LIGHT AND USB

B-3460-7/-5-QHFL/ B-3460-7/-5-QKR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.


2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.


4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

| NO. | PART DESC | CODE | Q'TY |
|-----|--------------------------|-------------------|------|
| А | HEADBOARD | B-3460-7-QHFL | 1 |
| В | HEADBOARD LEG - LEFT | PB-3460-7-HBLEGCT | 1 |
| С | HEADBOARD LEG - RIGHT | PB-3460-7-HBLEGCT | 1 |
| D | STRETCHER | PB-3460-7-QHSTRCT | 1 |
| Е | FOOT BOARD | B-3460-7-QHFL | 1 |
| F | KING/QUEEN BED SIDE RAIL | B-3460-7-QKR | 2 |
| G | SUPPORT LEG WITH LEVELER | PB-3460-BDSPLCT | 4 |
| Н | SLAT PB-3460-QBSLTCT | | 4 |

| | HARDWARE LIST FOR QUEEN BED | | | | | |
|-----------------------------|------------------------------------|---------------------------|----------------|------|--|--|
| NO. | | HARDWARE DESC | CODE | Q'TY | | |
| 1 |) | JCBB BOLT (M8 x 1-9/16") | | 10 | | |
| 2 | \odot | SPRING WASHER (M8 x 5/8") | | 10 | | |
| 3 | Ö | FLAT WASHER (M8) | PB-3460-KBHWCT | 10 | | |
| 4 | 0000000000 CSK SCREW (M4 x1 3/16") | | | 8 | | |
| 5 | | ALLEN KEY (M5) | | 1 | | |
| 6 | 0 | JCBC (M6 x2 3/4 ") | | 4 | | |
| 7 | SPRING WASHER (M6 x 3/8") | | | 4 | | |
| 8 | FLAT WASHER (M6 x 1/2") | | PB-3460-SHADCT | 4 | | |
| 9 | 9 | NUT M6 | PB-3460-SHADCT | 4 | | |
| 10 | - | ALLEN KEY M4 | | 1 | | |
| 11 | Å | SHADE | | 2 | | |
| 12 | | BULB | PB-3460-BULBCT | 2 | | |
| 13 | Ĩ, | POWER CABLE | PB-3460-CABCT | 1 | | |
| 14 | Ż | Y-CABLE | PD-3400-CABC1 | 1 | | |
| 15 | USB PORT | | PB-3460-USB2CT | 1 | | |
| HARDWARE LOCATED IN LEG BOX | | | | | | |



QUEEN BED WITH LIGHT AND USB B-3460-7/-5-QHFL/ B-3460-7/-5-QKR





FULL BED WITH LIGHT AND USB B-3460-7/-5-FHFL/ B-3460-7/-5-TFR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.


3. Please do not over tighten screws or bolts.

| | PART LIST FOR FULL BED | | | | | |
|-----|---|-------------------|------|--|--|--|
| NO. | PART DESC | CODE | Q'TY | | | |
| Α | HEADBOARD | B-3460-7-FHFL | 1 | | | |
| В | HEADBOARD LEG - LEFT | PB-3460-7-HBLEGCT | 1 | | | |
| С | HEADBOARD LEG - RIGHT | PB-3460-7-HBLEGCT | 1 | | | |
| D | STRETCHER | PB-3460-7-FHSTRCT | 1 | | | |
| Е | FOOT BOARD | B-3460-7-FHFL | 1 | | | |
| F | KING/QUEEN BED SIDE RAIL | B-3460-7-TFR | 2 | | | |
| G | SUPPORT LEG WITH LEVELER | PB-3460-BDSPLCT | | | | |
| Н | H SLAT PB-3460-FBSLTCT | | | | | |
| | Only tighten all bolts when all bolts aligned with bolt inserts | | | | | |

| | HARDWARE LIST FOR FULL BED | | | | | | |
|------|-----------------------------|---------------------------|----------------|------|--|--|--|
| NO. | | HARDWARE DESC | CODE | Q'TY | | | |
| 1 | 9 | JCBB BOLT (M8 x 1-9/16") | | 10 | | | |
| 2 | 0 | SPRING WASHER (M8 x 5/8") | | 10 | | | |
| 3 | Ø | FLAT WASHER (M8) | PB-3460-KBHWCT | 10 | | | |
| 4 | Sourceman . | CSK SCREW (M4 x1 3/16") | | 8 | | | |
| 5 | | ALLEN KEY (M5) | | 1 | | | |
| 6 | 0 | JCBC (M6 x2 3/4 ") | | 4 | | | |
| 7 | 0 | SPRING WASHER (M6 x 3/8") | | 4 | | | |
| 8 | 0 | FLAT WASHER (M6 x 1/2") | PB-3460-SHADCT | 4 | | | |
| 9 | 9 | | | 4 | | | |
| 10 | | ALLEN KEY M4 | | 1 | | | |
| 11 | Å | SHADE | | 2 | | | |
| 12 | | BULB | PB-3460-BULBCT | 2 | | | |
| 13 | Ĩ, | POWER CABLE | PB-3460-CABCT | 1 | | | |
| 14 | Ì | Y-CABLE | PD-3400-CADC1 | 1 | | | |
| 15 | | USB PORT | PB-3460-USB2CT | 1 | | | |
| *HAR | HARDWARE LOCATED IN LEG BOX | | | | | | |



FULL BED WITH LIGHT AND USB B-3460-7/-5-FHFL/ B-3460-7/-5-TFR



TWIN BED WITH LIGHT AND USB B-3460-7/-5-THFL/ B-3460-7/-5-TFR


Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.

2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.

3. Please do not over tighten screws or bolts.

| PART LIST FOR FULL BED | | | | | HARDWARE LIST FOR FULI | BED | | |
|------------------------|---|-------------------|------|-----|------------------------|---------------------------------------|----------------|------|
| NO. | PART DESC | CODE | Q'TY | NO. | NO. HARDWARE DESC | | CODE | Q'TY |
| А | HEADBOARD | B-3460-7-THFL | 1 | 1 |) | JCBB BOLT (M8 x 1-9/16") | | 10 |
| В | HEADBOARD LEG - LEFT | PB-3460-7-HBLEGCT | 1 | 2 | $\overline{\bigcirc}$ | SPRING WASHER (M8 x 5/8") | | 10 |
| С | HEADBOARD LEG - RIGHT | PB-3460-7-HBLEGCT | 1 | - | 0 | · · · · · · · · · · · · · · · · · · · | | 10 |
| D | STRETCHER | PB-3460-7-THSTRCT | 1 | 3 | | FLAT WASHER (WO) | PB-3460-KBHWCT | 10 |
| Е | FOOT BOARD | B-3460-7-THFL | 1 | 4 | Sourceman . | CSK SCREW (M4 x1 3/16") | | 8 |
| F | KING/QUEEN BED SIDE RAIL | B-3460-7-TFR | 2 | 5 | | ALLEN KEY (M5) | | 1 |
| G | SUPPORT LEG WITH LEVELER | PB-3460-BDSPLCT | 4 | 6 | <u></u> | JCBC (M6 x2 3/4 ") | | 2 |
| Н | SLAT | PB-3460-TBSLTCT | 4 | 7 | Ö | SPRING WASHER (M6 x 3/8") | - | 2 |
| | | | | 8 | 0 | FLAT WASHER (M6 x 1/2") | PB-3460-SHADCT | 2 |
| | | | | 9 | 9 | NUT M6 | | 2 |
| | | | | 10 | | ALLEN KEY M4 | | 1 |
| | | | | 11 | Â | SHADE | | 1 |
| | | | | 12 | ð | BULB | PB-3460-BULBCT | 1 |
| | | | | 13 | | POWER CABLE | PB-3460-CABCT | 1 |
| | | | | 14 | | Y-CABLE | | 1 |
| \triangle | Only tighten all bolts when all bolts aligned with bolt inserts | | | 15 | | USB PORT | PB-3460-USB2CT | 1 |



TWIN BED WITH LIGHT AND USB B-3460-7/-5-THFL/ B-3460-7/-5-TFR

