



TOUCH SCREEN GUIDE


4-Door Fridge with Kitchen Assistant™




CONNECT




AMBIENT



SCAN-TO-LIST




LIST




RECIPES




CONTROLS




HOME



PRECISE FILL



AUTOFILL



WATER


Table of Contents

Content	Page(s)
Getting Started (Commissioning the unit, connecting to Wi-Fi, and connecting your fridge to SmartHQ)	3-19
Personalize your fridge appearance	20-28
Water bar	29
Navigating the home screen	30-31
Scan-to-List	32-33
Shopping List	34-37
Recipe content	38-40
Precise Fill	41-42
Hands-free AutoFill	43
Fridge Controls	44-51
Water center	52-55
Kitchen Timers	56
Changing your Wi-Fi	57-59



Getting Started

Click "GET STARTED"



SKIP

Welcome to your
Kitchen Assistant™

Manage shopping lists, plan meals, and reduce food waste with a virtual kitchen assistant to keep ingredients fresh, meals inspired, and your kitchen organized.


- 1 Connect to WiFi
- 2 Download the SmartHQ app
- 3 Connect fridge to SmartHQ™

Why get connected to WiFi? ⓘ

GET STARTED

Getting Started


Click "CONTINUE"





SmartHQ Features

Scan-to-List

Scan any item with a bar code as you run out to automatically add them to your shared, digital grocery list to reference at the store or sync for grocery delivery.

 Profile


 **CONTINUE**

 < Home Water AutoFill Cubed

The image shows a smart refrigerator's touchscreen interface. On the left, a white panel displays the 'Scan-to-List' feature description. On the right, a hand holds a pink can of 'Lavender Lemonade Kombucha Beverage' in front of a scanner. The screen shows the product name, price (12.62), and ingredients. A 'CONTINUE' button is overlaid on the bottom right of the screen, with a white hand icon pointing to it. At the bottom, a dark navigation bar contains a back arrow, a home icon, and three selection buttons: 'Water', 'AutoFill', and 'Cubed'. The top of the screen shows a status bar with the time 11:20 AM and signal strength icons.

Getting Started


Click "CONTINUE"



SmartHQ Features

Fridge Focus™


View your fridge drawer contents from anywhere, helping you plan grocery lists while you're away from the fridge and avoid buying duplicates at the store

 Profile

LEFT DRAWER
Today, 4:54 PM

Camera History


CONTINUE

<  Water AutoFill Cubed

The image shows a person's hand holding a smartphone in a grocery store aisle. The phone screen displays the 'Fridge Focus' app interface, which shows a camera view of a refrigerator drawer containing various vegetables like lettuce, tomatoes, and purple cauliflower. Below the camera view is a 'Camera History' section with a grid of small thumbnail images. A purple button with the word 'CONTINUE' in white is overlaid on the bottom right of the phone screen, with a white hand icon pointing at it. The background of the phone screen is a blurred grocery store aisle with shelves of produce. At the top of the phone screen, the status bar shows the time as 11:21 AM, along with signal and battery icons. At the bottom of the phone screen, there are three navigation buttons: 'Water', 'AutoFill', and 'Cubed'. To the left of these buttons is a home icon and a back arrow. The entire scene is framed within a white border, suggesting it's a screenshot from a presentation or tutorial.

Getting Started

Click "CONTINUE"



Getting Started

Click "CONTINUE"

Precise Fill

No matter what container you're using, dispense an exact amount of filtered water with just a touch by using the Precise Fill setting.




Water

AutoFill

Cubed

Getting Started

Click "CONTINUE"




Getting Started

Click "CONTINUE"

SmartHQ Features

SmartHQ Voice Assistant

Just say "Hey HQ!" to get started with SmartHQ Voice Assistant. Add items to your shopping list, dispense water, set a timer, or ask about your appliance. Enable in Settings.

 Profile

Hey HQ!

add apples to my list


Apples added to the List.

CONTINUE

< Home Water AutoFill Cubed


Getting Started

Click "CONTINUE"



Getting Started

Click "GET STARTED"



The screenshot shows a dark-themed setup screen for the Kitchen Assistant. At the top right is a "SKIP" link. The main heading is "Welcome to your Kitchen Assistant™". Below this is a paragraph describing the app's features: "Manage shopping lists, plan meals, and reduce food waste with a virtual kitchen assistant to keep ingredients fresh, meals inspired, and your kitchen organized." To the right of this text is a numbered list of three steps: 1. Connect to WiFi, 2. Download the SmartHQ app, and 3. Connect fridge to SmartHQ™. At the bottom left is a link "Why get connected to WiFi?" with an information icon. At the bottom right is a large "GET STARTED" button with a hand cursor pointing to it.

SKIP

Welcome to your
Kitchen Assistant™

Manage shopping lists, plan meals, and reduce food waste with a virtual kitchen assistant to keep ingredients fresh, meals inspired, and your kitchen organized.


- 1 Connect to WiFi
- 2 Download the SmartHQ app
- 3 Connect fridge to SmartHQ™

Why get connected to WiFi? ⓘ

GET STARTED


Getting Started

Select your time zone and click "NEXT"




Getting Started

Select your WiFi network.





Getting Started

Type your password then click "NEXT"



Getting Started

WiFi connection confirmation



Create a SmartHQ™ Account (Or use the account you already have!)

Download the SmartHQ™ app



 iPhone

<https://apps.apple.com/us/app/smarthq/id992883749>




Google Play

https://play.google.com/store/apps/details?id=com.ge.kitchen&pcampaignid=web_share

Note: for everyone in the household to have access to the refrigerator and shared, digital shopping list on SmartHQ, you will be sharing a log-in and password. You will both use that log in on your own devices.

Creating a SmartHQ™ Account

<https://accounts.brillion.geappliances.com/account/register>



The image shows a registration form for a SmartHQ account. At the top, there is a navigation bar with the SmartHQ logo and several brand logos: Haier, iOmate, FISHER & PAYKEL, and Profile. The main heading is "Register New Account" with a subtext "Use your email and create a password to create a new account." The form contains several input fields: "Email Address*", "New Password*" (with a strength indicator showing "none"), and "Confirm Password*". There are also dropdown menus for "Country*" (set to "United States") and "Language*" (set to "English (U.S.)"). A checkbox at the bottom indicates agreement with the Privacy Statement and End User License Agreement. A prominent purple "SIGN UP" button is located below the checkbox. At the bottom of the form, there is a link for users who already have an account: "Already have an account? [Sign In](#)". The footer of the form contains the copyright notice: "Copyright 2018-2026 GE Appliances, a Haier company".


Connect your fridge to your SmartHQ™ account

Scan the QR code with your phone camera to sync to SmartHQ

Then enter the 5 digit code under the QR code when prompted

(easiest option)


Code for example only




OR manually type your SmartHQ account email and password onto the appliance

Connect to SmarthQ

You can confirm you're connected when you see "Sign Out"




Personalize your fridge



Access the settings shade by holding your finger on the gray bar and swiping down.



Settings Shade – Quick Controls

Dispenser Light Lock Controls Microphone On/Off Expanded Appliance Settings



Settings Shade – Ambient Screen / Screensaver

Choose whether you want the clock, date, or weather displayed on the left of the ambient screen



Clock Show/Hide

Date Show/Hide

Weather Show/Hide

Widgets Show/Hide


3-Day Weather Widget

Rotating Recipe Widget

Choose whether you want widgets on the right of the ambient screen


Settings Shade

Access the settings shade by holding your finger on the gray bar and swiping down.




Settings Shade – Ambient Screen / Screensaver

This is an example of the ambient screen when you have all options selected




Settings Shade – Ambient Screen / Screensaver


This is an example of the ambient screen when you have all options removed for a clean aesthetic.



Settings Shade – Ambient Screen / Screensaver




Scroll up to change the ambient screen wallpaper




Click Select Backdrop to browse ambient screen wallpapers

Settings Shade – Ambient Screen / Screensaver




Select one wallpaper or select multiple that will rotate

Click "clear all" to start over



Scroll to the right to see more options or click the categories above to skip forward


Settings Shade – Display & Appearance



Screen Brightness Level


Energy Saver Mode On/Off

Specify Energy Saver Window




Water Bar

The water bar stays on every screen for easy access to filtered water and ice. When you select cubed ice you also can toggle to crushed ice.



Home Screen

To access more features, swipe to the left.



Home Screen





This is a view of the features as you swipe left on the home screen.

Shortcuts

Shopping List

SmartHQ Assistant

Meal Planning My Fridge Stay Informed



Rotating Recipe Widget

Recipes

Taste of Home Recipes

Water Center

Fridge & Freezer Controls

Precise Fill


Weather

Scan-to-List

Our database contains over 4 million UPC codes from all categories of items: pantry items, fridge items, frozen goods, baking, drinks, pet supplies, baby items, home goods, self care items, toiletries, supplements, home improvement, school and office supplies, and cleaning supplies.

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



Lavender Lemonade Kombucha Beverage
Elixir
12 oz


Ingredients

organic raw kombucha (filtered water, organic cane sugar, organic black tea, organic kombucha culture), lemonade, organic lavender

Water AutoFill Cubed

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



Cascade Platinum Plus Dishwasher Pods Dishwasher Detergent Dish Detergent...
Cascade
32 oz


Item Description

New and Improved Cascade Platinum Plus ActionPacs dishwasher detergent gives your dishes a breakthrough

Water AutoFill Cubed

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



King Arthur Gluten Free Muffin Mix
King Arthur
16 oz


Ingredients

Cane Sugar, Whole Grain Brown Rice Flour, Potato Starch, Tapioca Starch, Cellulose, Baking Powder (Baking Soda, Calcium Acid Pyrophosphate, Monocalcium Phosphate), Salt,

Water AutoFill Cubed

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



Tide Original Scent Liquid Laundry Detergent
Tide
80 oz


Item Description

Face it, the world can be a really dirty place. In a world where common stains can be mere moments away, you need a clean that can stand up to them. When it comes to stains,

Water AutoFill Cubed

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



Dog Chow Complete Adult Dry Dog Food Kibble With Chicken Flavor
Purina
18.5 lb


Item Description

Your dog deserves an irresistibly tasty, 100 percent nutritionally complete and balanced dog food to keep them

Water AutoFill Cubed

Shopping List BETA 10:32 AM

List
Favorites
Previous Scan
Cart



Plant Based General Tso's Gluten Free Frozen Dinner
Saffron Road®
10.5 oz

Ingredients

White Rice (White Rice, Water, Expeller Pressed Sunflower Oil), Dumplings (Cauliflower, Chickpea Flour, Expeller Pressed Sunflower Oil, Ginger, Red Onions, Water, Green

Water AutoFill Cubed

Scan-to-List

This is how you scan an item onto your shared, digital shopping list.

Hold item halfway up the dispenser on the right side under the scanner.



You will see the item populate on screen.

The screenshot shows the 'Shopping List' app interface. The top navigation bar includes 'List', 'Favorites', 'Previous Scan', and 'Cart'. The main content area displays the scanned item: 'Lavender Lemonade Kombucha Beverage' with a quantity of 1. The item's name is annotated with 'Image' and 'Name'. The brand 'Elixir' is annotated with 'Brand'. The quantity '12 oz' is annotated with 'Adjust Quantities'. The 'Add to Favorites' button is annotated with 'Add to Favorites'. The ingredients list is annotated with 'Ingredients'. A hand icon pointing to the bottom of the screen is annotated with 'Scroll up for description'. The bottom navigation bar includes 'Water', 'AutoFill', and 'Cubed' options.

Image

Name

Brand

Adjust Quantities


Add to Favorites

Ingredients

Scroll up for description

Shopping List


View your entire list. The most recent item will be at the top.




Shopping List

For items without a bar code like an apple or orange, manually type it in.

Click the (+) button.





Type in your item such as "2 Honeycrisp apples" and click enter.



Shopping List

Your shared, digital shopping list is on the home screen of your SmartHQ account.



Export to PDF, email, or text list to someone not using SmartHQ

Check items off as you shop


Add to favorites to reference later

Add items to your list from your phone

Add the list to your cart


Instacart

You can sync your shared, digital shopping list to Instacart for grocery delivery.




Integrated Recipes

Swipe up to explore various recipes. Click your favorite.




Integrated Recipes

On the ingredients tab, select items and easily add them to your shopping list by clicking "Add to List."





Integrated Recipes

On the instructions tab, scroll up to view recipe steps. You can also view the recipe on your phone.




Precise Fill

Toggle between ounces, cups, quarts, or milliliters. Increase or decrease amounts.



Precise Fill

Either use Precise Fill hands-free or push the water paddle with larger containers.




Press Dispense to use Hands-free Precise Fill when a container can stand in the dispenser area hands-free.




Push the paddle with larger containers such as mixing bowls. If you lift the container off the paddle before reaching your set amount, it will pause Precise Fill.

Hands-free AutoFill

Hands-free AutoFill uses sensors in the refrigerator dispenser to release the exact amount of filtered water you want, so you can walk away while your bottle fills up.





Tap to activate



Ounces are counted as it fills

Tap X to cancel

Fridge Controls - Fridge



BETA 10:32 AM

Fridge Controls

Fridge

Middle Drawer

Freezer

Ice Maker

Lighting

Advanced

Fridge

+

37°

Recommended

-

TurboCool

8-Hour Rapid Chill Cycle


Increase fresh food temperature

Current set temperature


Decrease fresh food temperature

Toggle to activate TurboCool

Fridge Controls - Fridge




These are the set temperature options for the fresh food section.





Your fridge can display set temperatures in Fahrenheit or Celsius, which can be selected in the Advanced section of the fridge controls.

Fridge Controls – Middle Drawer



Tap your preferred setting to change your adjustable temperature drawer

Fridge Controls - Freezer



BETA 10:32 AM

Fridge Controls

Fridge

Middle Drawer

Freezer

Ice Maker

Lighting

Advanced

Freezer

+

0°

Recommended

-

TurboFreeze

8-Hour Rapid Chill Cycle


Increase freezer temperature

Current set temperature


Decrease freezer temperature

Toggle to activate TurboFreeze

Fridge Controls - Freezer





These are the set temperature options for the freezer section.



Your fridge can display set temperatures in Fahrenheit or Celsius, which can be selected in the Advanced section of the fridge controls.



Fridge Controls – Ice maker



Full ← Status will display full or making ice

← Ice maker can be toggled on or off

Fridge Controls - Lighting



Fridge Controls

Fridge
Middle Drawer
Freezer
Ice Maker
Lighting
Advanced

Lighting

Showcase LED Light Wall On

Light Wall Dimming

Presence Sensor On

Dispenser Sensor Lighting On

The dispenser light will automatically turn on when near the fridge.

BETA 10:32 AM

Water AutoFill Cubed


Toggle LED Light Wall on or off

Choose the brightness of the LED Light Wall

Bar code scanner presence sensing

Choose whether you want the dispenser light to come on when you approach the fridge

Fridge Controls - Advanced




Toggle Door Alarm on or off where the unit will beep if you forgot to close any of the doors

Choose between Fahrenheit or Celsius temperature settings

Put the unit in Sabbath mode

Water Center

Track your hydration.




← Daily ounces dispensed

← Daily average ounces dispensed

← Number of plastic bottles saved from entering the environment by using a refillable water bottle


Water Center

Track your filter usage and prepare to buy a new filter




Water Center

You will receive alerts when your filter has expired.



Water Center


Scan the QR code to purchase a new XWFE filter



Kitchen Timers


Set Kitchen Timers from the widget on the home screen.

Click box to expand the timer box



Pause the timer
Restart the timer

Name the timer by clicking the pencil




Click start after
you type your
desired timer

Type the timer
you want to set


Change your Wi-Fi

Access the settings shade by holding your finger on the gray bar and swiping down.




Change your Wi-Fi


Access Settings



Change your Wi-Fi



Select your home network



Enter your password

Click connect

GE Profile 4-Door Fridge with Kitchen Assistant™

