

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 1: 11/16/2020



ITEM: 422755Q



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.

 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

Z - HARDWARE


1	BOLT(Ø1/4"x13MM)		34PCS	4	ALLEN WRENCH(1/4")	1PC
2	BOLT(Ø 1/4"x36MM)	(a) Innininin	10PCS	5	OPEN WRENCH(1/4")	1PC
3	BOLT(Ø 1/4")		6PCS			

ITEM: 422755Q


ASSEMBLY INSTRUCTIONS




<u>STEP 1</u>




STEP 2



<u>STEP 3</u>



<u>STEP 4</u>




PAGE 3 **OF** 4


ITEM: 422755Q


ASSEMBLY INSTRUCTIONS



<u>STEP 5</u>







Note: Dimension tolerance ±5%

