


ASSEMBLY INSTRUCTIONS

D1903-30 **MAISIE SERVER**

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

PARTS LIST				
NO	DESCRIPTION	SKETCH	QTY	
1	TABLE TOP		1 PC	
2	TOP PANEL		1 PC	
3	LEG		4 PCS	
4	SIDE PANEL		2 PCS	
5	SIDE PANEL WINE RACK		2 PCS	
6	MIDDLE PANEL		1 PC	
7	DOOR PANEL (L/R)		2 PCS	
8	BACK PANEL		1 PC	
9	BOTTOM PANEL		1 PC	

HARDWARE LIST				
NO	DESCRIPTION	SKETCH	QTY	
A	JCBB BOLT - M8 x 60mm	©	8 PCS	
В	FLAT WASHER - M8	0	8 PCS	
С	SPRING WASHER - M8		8 PCS	
D	ALLEN KEY - M5		1 PC	
E	WOOD DOWEL		16 PCS	
F	L BRACKET		6 PCS	
G	CSK SCREW - M3.5 x 12mm	D unn	12 PCS	




IMPORTANT NOTE:


* Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.



ASSEMBLY INSTRUCTIONS


D1903-30 MAISIE SERVER






Step 3.

PLACE THE BACK PANEL (8) INTO THE FLUTE AND THEN ASSEMBLE THE TOP PANEL (2) TO THE SIDE PANEL (4) AND DIVIDER PANEL (5).



Step 4. SLOT IN THE MIDDLE SHELF (6) INTO THE DIVIDER PANEL (5).






ASSEMBLY INSTRUCTIONS

D1903-30 MAISIE SERVER


Step 5.

SERVER TOP HAVE SHOWN STICKER (B) FOR TOP BACK SIDE. PLEASE ASSEMBLY THE SERVER TOP (STICKER B) AT BACK SIDE.



Step 7.

UNLOCK THE DOOR BEFORE PLACING THE DOOR PANEL(7) INTO THE FLUTE THEN PUSH BUTTON LOCK TO ENSURE THE DOOR STAY BETWEEN THE FLUTE.



Step 6. IMPORTANT:
TO SECURE THE CENTER SHELF IN PLACE,
THE L BRACKETS MUST BE INSTALLED AS
SHOWN ON STEP 6.

