

ALEXANDRA FULL/QUEEN STORAGE BED ASSEMBLY INSTRUCTIONS





BOX #3 C. LEFT SIDE RAIL: 1 PC D. RIGHT SIDE RAIL: 1 PC E. CENTER SLAT SUPPORT: 1 PC F. SLAT SUPPORT LEG: 2 PCS

BOX #2 B. STORAGE FOOTBOARD: 1 PC G. SLAT ROLL: 1 SET H. METAL STRETCHER: 1 PC



FULLY ASSEMBLED



HARDWARE PACKED IN BOX #2

1	ALLEN BOLT (M8X50)		8 PCS
2	ALLEN BOLT (M6X60)	(A)	2 PCS
3	SPRING WASHER (M8)	0	8 PCS
4	FLAT WASHER (M8)	0	8 PCS
5	WOOD DOWEL (M8X30)		4 PCS
6	WOOD SCREW (M4X30)	Samurana.	6 PCS
7	ALLEN KEY		1 PC

TOOL REQUIRED PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)





MODUS ALEXANDRA FULL/QUEEN STORAGE BED **ASSEMBLY INSTRUCTIONS** STEP 1: (A)D STEP 2: STEP 3:

ALEXANDRA FULL/QUEEN STORAGE BED **ASSEMBLY INSTRUCTIONS**










STEP 5:




INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each support leg.

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each support leg is applying equal, upward pressure on the bed support slat.




MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it. Dragging can damage the leg support.
- Readjust levelers after moving your bed.


ALEXANDRA CAL KING/KING STORAGE BED ASSEMBLY INSTRUCTIONS






BOX #2

B. STORAGE FOOTBOARD : 1 PC G. SLAT ROLL : 1 SET H. METAL STRETCHER : 1 PC




FULLY ASSEMBLED



HARDWARE PACKED IN BOX #2

1	ALLEN BOLT (M8X50)		8 PCS
2	ALLEN BOLT (M6X60)	(A)	4 PCS
3	SPRING WASHER (M8)	0	8 PCS
4	FLAT WASHER (M8)		8 PCS
5	WOOD DOWEL (M8X30)		8 PCS
6	WOOD SCREW (M4X30)	Gymminus.	8 PCS
7	ALLEN KEY		1 PC


TOOL REQUIRED PHILLIPS HEAD SCREW DRIVER (NOT PROVIDED)




MODUS ALEXANDRA CAL KING/KING STORAGE BED **ASSEMBLY INSTRUCTIONS** STEP 1: (A)STEP 2: STEP 3:

ALEXANDRA CAL KING/KING STORAGE BED ASSEMBLY INSTRUCTIONS








INSTRUCTIONS FOR ADJUSTING LEVELER:

Position the bed in your space and locate the leveler under each support leg.

Turn the leveler counter-clockwise to extend the leveler and clockwise to retract it.

Adjust each leveler until each support leg is applying equal, upward pressure on the bed support slat.



MAINTENANCE INSTRUCTION:

- Remove box spring and mattress before moving your bed.
- Lift your bed when moving it.

 Dragging can damage the leg support.
- Readjust levelers after moving your bed.