




COMMERCIAL AUTOMATIC WASHER

MODELS:

MAT20MNAWW1 (White)


TOP AND CABINET PARTS



TOP AND CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	13	90016	Clip, Harness	29	356138	Clamp, Hose
	W10837721	Installation Instructions	14	W10482836	Latch, Lid Lock Assembly	30	W10339879	Tie, Cable
	W10838047	Tech Sheet	15	W10588613	Screw	31	54583	Hinge, Lid Right Hand
2		Top	16	W10250884	Panel, Rear	32	W10461181	Bushing-Top, Screw
	W11349835	White	17		Cabinet	33	90406	Nut, Cage
3		Assembly, Lid and Bumper		W10845574	White	34	W10318627	O-Ring
	W11349836	White	18		Brace, Cabinet Top - Front	35	W10486616	Screw
4	W11241723	Bumper, Lid		W10724131	White	36	3359452	Nut, Hex
5	9740848	Screw	19	W11089573	Brace, Cabinet Top - Rear	37	21097	Pad, Lid Hinge
6	91770	Hinge, Lid (Left Hand)	20	W10660565	Screw	38	W10850379	Bracket, Base Panel, Front
7	W10119872	Screw	21	W10461182	Lock, Top	39	W10811028	White
8		Strike, Lid Lock	22	W10245373	Foot, Leveling	40	W10866521	Bracket, Front Panel
	W10240513	White	23	W10461176	Hinge, Top	41	8283273	Damper, Brace
9	W10273971	Screw	24	W10142728	Screw	42	W10862638	Lock, Top Front
10	W10015090	Screw	25	W10461180	Cover, Harness	43	W11096159	Damper, Sound
11		Bezel, Lid Lock	26	3400076	Screw	44	W10866523	Rivet
	W10392041	White	27	W11203364	Hose, Outer Drain Assembly	45	W11129581	Bracket, Front Top
12	21258	Bearing, Lid Hinge	28	W10280024	U-Bend, Drain Hose	46	W10161707	Top, Foam Seal
						47	356907	Rivet, Plastic


CONTROLS AND WATER INLET PARTS



CONTROLS AND WATER INLET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11124005	Console	10		Knob & Bumper Assembly	18	W10829504	Fascia
2	W10131119	Screw M4X13				19	W10131123	Nut, "U"
3	W11298479	Control Unit Assembly, Machine & Motor		W10461097	Gray	20		Hose, Water Inlet
4	W10461159	Panel, Console Rear Cover	11	W10285518	Switch, Rotary Encoder (5 Position)		W10852720	Cold Water
5	W10660565	Screw	12	W10694672	Harness, Upper E-Star		W10852721	Hot Water
6	90767	Screw	13	W10843663	Inlet Assembly, Water	21	W10843661	Harness, LED
7	W10916256	Cord, Power	14	W10843398	Harness, Valve	22	W11032871	Relay
8	3400076	Screw	15	W10461117	Push Button, Start	23	W10510149	Bezel - PTS
9		Assembly, Timer Knob	16	W10461066	Bracket, Back	24	W10242307	Washer, Hose
	W10133504	Gray	17	W10828903	Insert, Encoder Stop (7 Position)			


BASKET AND TUB PARTS



BASKET AND TUB PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10131111	Cap, Agitator	9	21366	Nut, Spanner	15	W10238320	Tub
2	W10003790	Screw and Washer	10	W10198148	Block, Basket Drive	16	W10843660	Harness, Lower (Includes Pressure Hose)
3	3949550	Washer	11	W10215093	Filter, Drain Pump	17	W10531633	Hose, Pressure Switch
4	W10131112	Agitator	12	8533928	Screw	18	W10005430	Clamp, Cable
5	W10755559	Rubber Washer, Impeller	13	W10839119	Strap, Snubber	19	8533943	Screw
6	W10424289	Adapter, Balance Ring	14	W10821942	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Balls and Suspension Bushings)			
7	W10461196	Ring, Tub						
8	W10389330	Basket Assembly						

GEARCASE, MOTOR AND PUMP PARTS



GEARCASE, MOTOR AND PUMP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10276397	Pump Assembly, Drain	6	W10249633	Screw	12	W10625042	Capacitor, Motor Run
2	W10004910	Screw	7	W10850134	Motor, Drive	13	W10427633	Shield, Pulley Cover
3	W10763078	Hose, Inner Drain Assembly	8	W10094780	Screw	14	357640	Screw
4	8317496	Clamp, Hose	9	W10850138	Belt, Drive	15	W10721967	Splutch Kit (60Hz)
5	W11261592	Assembly, Gearcase	10	W11112160	Actuator, Shift			
			11	9741052	Screw			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10135699	Affresh® Washer Cleaner
	8212526	Washer, Drip Tray
	W10576550	Main Top Rear Support

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10575888	Hose Fill Kit
	285834	Siphon Break Kit
	285835	Connector Assembly
	285863	4' Drain Hose w/Clamp
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	350008	Hose, Inlet (10')
	76314	Hose, Inlet (6' Hose With Elbow)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)