

Setup Guide

Téléviseur
Televisor digital a color con pantalla de cristal líquido
Televisor

5-048-782-11(1)



EN	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support
U.S.A.:
<https://www.sony.com/tvsupport>
Canada:
<https://www.sony.ca/support>
United States
1.800.222.SONY
Please Do Not Return the Product to the Store
Service à la clientèle Sony
Canada :
<https://www.sony.ca/support>
États-Unis :
<https://www.sony.com/tvsupport>
Canada
1.877.899.SONY
Ne retournez pas le produit au magasin


Lea este manual antes de usar el producto

Centro de Asistencia de Sony
<https://esupport.sony.com/ES/LA/>
Llame al número telefónico que aparece en su póliza de garantía.
Por favor no devuelva el producto a la tienda donde adquirió el producto.


BRAVIA XR

XR-98X90L


1




2




3




4



5




6




*1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados. / Exclusivo para regiões/países/modelos especificados.




7




8






9



10




11



*2 3.5/3.5 mm
1 2 3 4
1: L / G / L (Lzq.) / L (E)
2: Video / Vidéo / Video
3: GND / Tierra
4: R / D / R (Der.) / R (D)

*3




*4 < 21 mm
< 12 mm

*5 3.5/3.5 mm
1: Tx D
2: Rx D
3: GND / Tierra

*6 3.5/3.5 mm
1: IR
2: GND / Tierra

*7



*8 < 7 mm
< 1.5/1.5 mm