


ITEM: 753277



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

753278
COFFEE TABLE

ITEM : 753278



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructionin the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLE TIME	10 MINUTES
---------------	------------

PARTS IDENTIFICATION

B1: TOP




A  MIRROR CABINET 1PC

C  BASE 1PC

B2: LEG


B  LEG 2PCS

HARDWARE


1		BOLT 8x35MM	16PCS
2		WASHER Φ20x2MM	16PCS
3		ALLEN KEY 30x80MM	1PC

HARDWARE PACK IS LOCATED IN 753278 (B1)


ITEM : 753278
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2



STEP 3





Note : Dimension tolerance $\pm 5\%$