

## SIMPLE MANUAL

# Wireless Sound Bar

Please read this manual carefully before operating your set and retain it for future reference.

To view the instructions of advanced features, visit <a href="http://www.lg.com">http://www.lg.com</a> and then download Owner's Manual. Some of the content in this manual may differ from your unit.

MODEL

SL5Y



Copyright © 2019 LG Electronics Inc. All Rights Reserved.

#### FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

#### FCC Radio Frequency Interference Requirements:

High power radars are allocated as primary users of the 5.25 to 5.35 GHz and 5.65 to 5.85 GHz bands. These radar stations can cause interference with and/or damage this device. This device cannot be co-located with any other transmitter.

#### Supplier's Declaration of Conformity

Trade Name

Responsible Party LG Electronics USA, Inc.

1000 Sylvan Ave Englewood Cliffs, NJ 07632

(201)266-2215

Telephone





	LG Customer Information Center		
	1-800-243-0000 1-888-865-3026	USA, Consumer USA, Commercial	
Posistar vous aradust Online			

www.lg.com

Printed in China

SL5Y.DUSALLK\_SIM (Sheet)\_ENG\_MFL71440007.indd 1-4 2018-12-27 9:54:38




#### Front Panel



(1) (Standby) ······Switches the unit ON or OFF. ···Selects function. **─/+** (Volume)····· Adjusts volume.

### Rear Panel




..... Connect to the AC adapter. **OPTICAL IN** ......Connect to an optical device. ····Connect to device with HDMI OUT. **HDMI OUT (TV ARC)** ..... Connect to a TV. USB Port · · · · · · Connect to a USB device.

# TV Connection

Connect the sound bar and TV using Optical (A) or HDMI ARC (B).

- 1 Connect the sound bar to the TV using Optical
- 2 Set up [External Speaker (Optical)] on your TV setting menu.



#### Manual Subwoofer Connection

wireless subwoofer to the outlet.

If the subwoofer does not make sound, try to connect manually.

Subwoofer Connection

Place the wireless subwoofer near the sound bar and

1 Connect the power cord of the sound bar and the

• The sound bar and wireless subwoofer will be

automatically connected. The subwoofer's

- 1 Press Pairing on the rear of the wireless
- The green LED on the rear of the wireless subwoofer blinks quickly. (If the green LED does not blink, press and hold the Pairing.)
- 2 Turn on the sound bar.


follow steps below.

2 Turn on the sound bar.

green LED turns on.

• Pairing is completed. The green LED on the rear of the wireless subwoofer turns on.

Keep the sound bar and the subwoofer away from the device (ex. wireless router, microwave oven, etc.) over 1 m (3.3 ft) to prevent wireless interference.




- 1 Connect the sound bar to the TV using HDMI
- 2 Set up [External Speaker (HDMI ARC)] on your TV setting menu.



- HDMI connection is unavailable if your TV does not support HDMI ARC.
- If this unit is connected by OPTICAL and ARC at the same time, the ARC signal is a high priority.

## Additional Device Connection


1 Connect to the external device like as follow.




2 Set the input source by pressing F repeatedly.

#### Remote control

### Optical Connection




### B HDMI (ARC) Connection



## Additional Information

# Replacement of Battery



KM/DDI: Skip/Search

Bluetooth connection lock (BT LOCK): Select the **Bluetooth** function by pressing **F** repeatedly. Long press **NI** and press it again to limit Bluetooth connection to only BT and LG TV.

- TV remote: Long press SOUND EFFECT and

**FOLDER** ^/∨: Searches a folder.

Auto Power ON/OFF: Long press (i) and press

**111**: Adjusts sound level of each speaker.

Surround sound: Long press ## and press it

**REPEAT:** Listens to your files repeatedly or randomly.

**I:** Play/Pause

**SOUND EFFECT:** Selects a sound effect mode.

press it again to use TV remote control.

①: Displays the information of a file, an input source or connected Bluetooth device name.

## Specification

Power consumption	Refer to the main label.
AC adapter	<ul> <li>Model: DA-50F25</li> <li>Manufacturer: Asian Power Devices Inc.</li> <li>Input: 100 - 240 V ~ 50 - 60 Hz</li> <li>Output: 25 V === 2 A</li> </ul>
Dimensions (W x H x D)	Approx. 890.0 mm X 57.0 mm X 85.0 mm With foot (35 inch x 2.2 inch x 3.3 inch)
Bus Power Supply (USB)	5 V === 500 mA
Amplifier (Total RMS Output power)	400 W RMS

Design and specifications are subject to change without notice.

## Rear Speakers Ready

Ready for surround sound with Rear Speakers Kit sold separately. (SPK8-S)

#### OPEN SOURCE SOFTWARE NOTICE INFORMATION

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.







SL5Y.DUSALLK\_SIM (Sheet)\_ENG\_MFL71440007.indd 5-8 2018-12-27 9:54:40