

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

110035 <u>Counter Height Chair</u>

REVISION 0:10/24/2020 REVISION 1:01/02/2021

ITEM: 110035



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	SEAT AND BACK		1PC
В	LEFT FRONT LEG		1PC
С	RIGHT FRONT LEG		1PC
D	LEFT BACK LEG	0 -	1PC
E	RIGHT BACK LEG	0 -	1PC
F	FRONT STRETCHER	db	1PC
G	RIGHT SIDE STRETCHER	<u></u> b	1PC
Н	LEFT SIDE STRETCHER	ф	1PC
i	BACK STRETCHER		1PC
J	LOOSE SEAT CUSHION		1PC

HARDWARE IDENTIFICATION

1	BOLT (Ø5/16" x 1-3/16" - BLK)		8PCS
2	LOCK WASHER (Ø5/16" - RBW)		8PCS
3	FLAT WASHER (Ø5/16" - RBW)		8PCS
4	PAN HEAD SCREW (Ø8 x 50MM - RBW)	aaaaaaa(*)	8PCS
5	ALLEN WRENCH		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 110035

COASTER

ASSEMBLY INSTRUCTIONS STEP 1




STEP 2




ITEM: 110035


COASTER

ASSEMBLY INSTRUCTIONS STEP 3




STEP 4 COMPLETE











Note : Dimension tolerance ± 5%