

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / NO D'ARTICLE / ARTICULO NO. : P359302

DESCRIPTION/ LA DESCRIPTION /DESCRIPCIÓN : BUFFET / BUFFET / APARADOR





⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



A

- x1 Buffet
- x1 Buffet
- x1 Aparador

B



- x1 Furniture Tipping Restraint *
- x1 Systeme antibasculement
- x1 Control para evitar vultcos

*** Replaceable Part**

ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE

ITEM NO./ NO D'ARTICLE/ ARTICULO NO. : P359302
DESCRIPTION/ LA DESCRIPTION /DESCRIPCIÓN : BUFFET / BUFFET / APARADOR

A WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



STEP 1 ÉTAPE 1 PASO 1



★ Replaceable Part

REPLACEABLE PART / PARTIE REMPLAÇABLE / PARTE REEMPLAZABLE

ITEM NO. / NO D'ARTICLE/ ARTICULO NO. : P359302

DESCRIPTION/ LA DESCRIPTION /DESCRIPCIÓN : BUFFET / BUFFET / APARADOR

⚠ WARNING








Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!





 x1 RP359302-CE Center Support Leg Support central Soporte para la pata central	 x4 RP359302-HINGE-Door Hinge Charnière de porte Bisagra de la puerta	 x4 RP359302-CATCH-Door Catch Catch de aimant Captura de imán
 x16 RP359302-CLIP Shelf Clip Supports Pour Tablette Soporte De Las Repisas	 x3 COMGLIDE-10-45-Glide 10inch 45mm Glissière Carriti de deslizamiento	 x1 RP359302-TRAY - Jewelry tray Plateau de bijoux Bandeja de joyas
 x4 RP359302-SHELF-Wood Shelf Étagère Repisa/ Estante	 x4 RP359100-KNOBS-Knob with Screw (Small) Poignée + vis Tirador + Tornillo	 x6 RP359100-KNOBB - Knob with screw (Big) Poignée + vis Tirador + Tornillo
 x5 RC-FG-WHITE-White Leveler Patin réglable Nivelador	 x1 RC-ANT-TIP- Anti-tipping Restraint Système antibasculement Control para evitar vuelcos	

★ Replaceable Part

Protect Your Wood or Laminate Flooring

* This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floor without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.

** Replaceable Part*