

Assembly Instruction for SQUARE DINING TABLE D-7570-5-DTT / D-7570-5-DTB

CAUTION: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST


NO.	PART DESC	CODE	Q'TY
A	SQUARE DINING TABLE BASE IN DARK ESPRESSO - LEFT LEGS IN DARK ESPRESSO	PD-7570-5-DTBLEG	2
B	SQUARE DINING TABLE BASE IN DARK ESPRESSO - RIGHT LEGS IN DARK ESPRESSO	PD-7570-5-DTBLEG	2
C	SQUARE DINING TABLE TOP IN GREY - TOP MENDING PLATE IN BLACK	PD-7570-5-DTTTMP	1
D	SQUARE DINING TABLE TOP IN GREY - TOP IN GREY		1

HARDWARE LIST

NO.	HARDWARE DESC	CODE	Q'TY
1	 BOLT Ø5/16"x1-3/4"	PD-7570-DTHW	12
2	 LOCK WASHER Ø5/16"		12
3	 FLAT WASHER Ø5/16"		12
4	 ALLEN KEY M5		1


 Only tighten all bolts when all bolts aligned with bolt inserts.

Step:1




**Assembly Instruction for
SQUARE DINING TABLE
D-7570-5-DTT / D-7570-5-DTB**

Step:2




Step:3




**Assembly Instruction for
SQUARE DINING TABLE
D-7570-5-DTT / D-7570-5-DTB**

Step:4



Step:5



**Assembly Instruction for
SQUARE DINING TABLE
D-7570-5-DTT / D-7570-5-DTB**

COMPLETED

