

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204184
Mirror

REVISION 0 : 06/17/2015
REVISION 1 : 07/04/2017
REVISION 2 : 03/23/2018
REVISION 3 : 11/05/2019

ITEM:204184



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A


DRESSER
FROM BOX
ITEM 204183



1PC

C


MIRROR SUPPORT
(PACKED WITH
DRESSER)



2PCS

B

MIRROR




1PC

HARDWARE IDENTIFICATION

1


BOLT
(1/4" x 32mm - RBW)



6PCS

3


FLAT WASHER
(1/4" x 19 x 1.5mm - RBW)



6PCS

2


LOCK WASHER
(1/4" - RBW)



6PCS

4

ALLEN WRENCH
(4MM - RBW)




1PC

ITEM: **204184**



ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2 COMPLETE



ITEM:204184



Note: Dimension tolerance $\pm 5\%$