

# **ASSEMBLY INSTRUCTIONS.**

KENT OUTDOOR DINING CHAIR BLACK-SET OF TWO

QX-1017-02



THANK YOU FOR YOUR PURCHASE!

## PARTS AND HARDWARE.

#### **PARTS LIST**

No.	DESCRIPTION	IMAGE	QTY
P1	SEAT		1
P2	BACK		1
P3	LEG1		1
P4	LEG2		1

### **HARDWARE LIST**


No.	DESCRIPTION	IMAGE	QTY
Н1	BOLT(6X40MM)		5
H2	SPRING WASHER (6X10X1MM)	0	4
Н3	FLAT WASHER (6X12X1 MM)	0	5
H4	ALLEN KEY(M5)		1
H5	BOLT(6X16MM)	0	4
Н6	ALLEN KEY(M4)		1

## NOTES.


Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that may have come loose inside the carton during shipping

**CAUTION:** Ensure not to overtighten screws to reduce the risk of stripping or breakage.


STEP 1.



STEP 2.



STEP 3.



## STEP 4.

