

Assembly Instruction For COUNTER SIDE CHAIR D-17380-8-CSC

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST


No.	PART DESC.	CODE.	Q'TY
A	BACK FRAME WITH CUSHION	PD-17380-8-CSCBFR	1
B	SEAT FRAME WITH CUSHION	PD-17380-8-CSSEA	1
C	LHF FRONT LEG	PD-17380-8-CSCLEGL	1
D	RHF FRONT LEG	PD-17380-8-CSCLEGR	1
E	LHF / RHF STRETCHER	PD-17380-8-CSCSTR1	2
F	FRONT STRETCHER WITH METAL FOOTREST RAIL	PD-17380-8-CSCSTR2	1

HARDWARE LIST


No.	HARDWARE DESC.	CODE.	Q'TY
1	ALLEN BOLT (1/4"x 1-1/2")	PD-17380-CSCHW	2
2	ALLEN BOLT (1/4"x 2-1/4")		4
3	ALLEN BOLT (1/4"x 3")		4
4	SPRING WASHER (1/4")		10
5	FLAT WASHER (1/4" x 7/8")		10
6	SCREWS (#8x1-3/4")		6
7	ALLEN KEY (M4)		1

⚠ Only tighten all bolts when all bolts aligned with bolt inserts.

STEP:1



STEP:2



COMPLETED

