

#### **ASSEMBLY INSTRUCTION COASTER FINE FURNITURE**



REVISION 2 : 04/18/2023

PAGE 1 OF 4

### ITEM: 701077



## Assembly Instruction

#### ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

#### **A**Warning!

1.Don't attempt to repair or modify parts that are broken or defective.please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.



	DESCRIPTION	FIGURE	Q'TY
1	Bolt Ø 5/16X2"	() The second se	8PCS
2	Flat Washer Ø5/16	0	8PCS
3	Spring Wrench Ø19mm	0	8PCS
4	Allen Wrench 4mm		1PC
-25	PAGE 2 OF 4	WWW.CO	ASTERFURNITURE.CO











#### ASSEMBLY INSTRUCTION COASTER FINE FURNITURE





REVISION 0 : 07/04/2017 REVISION 1 : 05/16/2019 REVISION 2 : 04/18/2023

PAGE 1 OF 4

## ITEM: 701078



# Assembly Instruction

#### ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly.

3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

#### **A**Warning!

1.Don't attempt to repair or modify parts that are broken or defective.please contact the store immediately. 2.This product is for home use only and not intended for commercial establishment.



	DESCRIPTION	FIGURE	Q'TY
1	Bolt Ø 5/16X2"		8PCS
2	Flat Washer Ø5/16	0	8PCS
3	Spring Wrench Ø19mm	$\odot$	8PCS
4	Allen Wrench 4mm		1PC







