

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 01/04/2022

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 183471

ASSEMBLY INSTRUCTIONS



1PC

1PC

1PC


ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



-		Call Is
Е	RIGHT SIDE STRETCHER	
F	LEFT SIDE STRETCHER	
G		

G SEAT CUSHION WITH FRAME

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110MM - BLK)		1PC
2	LONG BOLT (M6 x 80MM - RBW)		4PCS
3	MEDIUM BOLT (M6 x 60MM - RBW)		4PCS
4	SHORT BOLT (M6 x 40MM - RBW)		2PCS
5	LOCK WASHER (1/4" - BLK)	Q	10PCS
6	FLAT WASHER (5/16" - RBW)	\bigcirc	10PCS
7	PAN HEAD SCREW (#8 X 1 1/2" - BLK)		6PCS

NOTE :

Phillips head screw driver is required in the assembly process ; However, manufacturer does not provide this item. Quantities shown are for one chair.

PAGE 2 OF 5

