

and Leg(C) for back leg of chair. making clear Leg (B) for front leg of chair Do not attempt to assemble the chair before

the screws are tightened completely. Do not try to seat or use before confirm all




## LA-A020LG-1




**ASSEMBLY INSTRUCTIONS** 

## **ASSEMBLY INSTRUCTION**




Place Table Top(A) upside down on a non-abrasive surface to avoid scratching the top.


Secure Bolts (E) and Washers(G) to connect Leg(B) and table top (A) Some adjustments may be necessary to ensue the legs are aligned properly.



Then Secure Bolts(E) and Washers(G) to connect Leg(B) and middle cross of table top (A), Repeat for another three Leg(B)



Pls secure screw all legs are tightened completely, totally 18pcs bolts, if you find the bolts can not be screwed tightened,pls return the table.




## **ASSEMBLY INSTRUCTION**

Α		1
В		2
С	<b>□</b>	2
D	0	4

Firstly make clear leg (B) and leg (C)before trying to assemble; Leg(B) is longer for front leg of chair ,Leg(C)is short for back leg of chair,

Then align the leg(B) and leg(C) with seat (A), screw the leg(C) and leg(B)

Be tightened until ensure there is no space. Some adjustments may be necessary to ensue the legs are aligned properly.



Pls secure screw all four legs are tightened completely,, if you find the legs can not be screwd tightenly ,pls return the chair.



## Need some help?

GIVE US A CALL: 1-888-980-5122 MON - FRI 8:30AM - 5:30PM (PT)



Outdoor furniture naturally weathers and shows color variation over time. We recommend the following care for the best results:

- Wipe with a soft cloth.
- Wash with mild soap and water as needed; do not use abrasive cleaners.
- Cover furniture with an outdoor cover (not included) when not in use.
- Store in a dry, covered area during inclement weather or winter season.



After assembly is completed, save these instructions and any included tools for future maintenance or re-assembly.