








Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. The product of Hillsdale Furniture, LLC is designed for residential use only. Customer Service Phone Number: 502-562-0000

HARDWARE LIST

- A (8) M8*30mm Allen Bolts
- B (8) M4*30mm Screws
- C (1) Allen Wrench
- D (8) Adjustable Feet
- E (4) M8*50mm Allen Bolts
- F (4) Spring Washers
- G (4) Flat Washers

PARTS LIST

- H (4) Slats
- I (8) Support Legs
- J (1) Footboard

PART	QTY	HARDWARE	PART	QTY	HARDWARE
A	8		B	8	
C	1		D	8	
E	4		F	4	
G	4		<div style="border: 1px solid black; padding: 5px;"> <p><i>The Side Rails (*) are not included. Sold Separately</i></p> </div>		

STEP 1 - Figure 1

Attach Side Rails to Footboard (J) using 2 Long Bolts (E), 2 Spring Washers (F) and 2 Flat Washers (G) per side. Hand tighten bolts only.

STEP 2 - Figure 2

Attach the Adjustable Feet (D) to the Support Legs (I) by screwing them into place.

STEP 3 - Figure 3

Attach Support Legs (I) to Slats (H) using 1 Short Bolt (A) per leg. Tighten all bolts with Allen Wrench (C) provided.

STEP 4 - Figure 4

Attach Slats (H) to Side Rails using 2 Wood Screws (B) per beam. Tighten with philips head screwdriver (not included). The assembly is now complete.

