

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 224337 ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PART IDENTIFICATION

Α	TABLE	1PC
в	FRONT LEG	2PCS
С	LEFT BACK LEG	1PC
D	RIGHT BACK LEG	1PC
Е	SHORT METAL STRETCHER	2PCS
F	LONG METAL STRETCHER	1PC


HARDWARE IDENTIFICATION


1	BOLT (M6 x 35mm - BLK)		8PCS
2	LOCK WASHER (1.6 x 14mm - BLK)	\bigcirc	8PCS
3	FLAT WASHER (1 x 18mm - BLK)	\bigcirc	8PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)		1PC
5	FLAT HEAD SCREW (8 x 2" - BLK)	(Yannininin)	6PCS
		PAGE 2 OF 5	

ITEM: 224337 ASSEMBLY INSTRUCTIONS



<u>STEP 1</u>






ITEM: 224337 ASSEMBLY INSTRUCTIONS



<u>STEP 3</u>





PAGE 4 OF 5

q

O

COASTERFURNITURE.COM

