

Dishwasher Power Cord Kit, Right Angle

W11365014

Available Finishes/Colours

W11365014 Other

Specifications

Country Of Origin

USA

Extended Service Plan

Parent

Product To Product Pairs

The Dishwasher Power Cord Kit, Right Angle is a ULlisted power supply cord that connects the dishwasher to the wall outlet and supplies electricity to the appliance. The kit includes (1) new power cord, (1) grommet, (1) metal strain relief and installation instructions. This product is an accessory item compatible with several brands; check to see if your model number is compatible. Installing this part will require basic hand tools, some disassembly of the dishwasher and novice repair experience. You must unplug the dishwasher or shut off the house circuit breaker for the appliance before installing this part. Helpful Tip: We also recommend using affresh® Dishwasher Cleaner* (item W10282479) to help remove limescale and mineral build-up that can be unsightly and affect your dishwasher's performance. *affresh® brand products are owned and distributed by Whirlpool Corporation.

Top Features

This product is a Factory Certified Accessory. These three words represent quality parts and accessories designed specifically for your appliance. Time tested engineering that meets our strict quality specifications