



Assembly Instruction

Collection: CARISSA

Item No: D422-20


CARISSA DINING CHAIR (2 PER CARTON)

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.

1. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not tighten screws or bolts until the assembly is completed.
3. To level the chairs or table, before tightening all the screws, the chairs or table must be placed on a flat surface and then tighten the screws.
4. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST			
No.	DESCRIPTION	SKETCH	Q'TY
A	CHAIR BACK		1
B	SEAT CUSHION		1
C	CHAIR LEG		2
WEIGHT CAPACITY (PER CHAIR)		308 LBS	

HARDWARE LIST			
No.	DESCRIPTION	SKETCH	Q'TY
1	LONG BOLT (5/16"x3-1/4")		4
2	MEDIUM BOLT (5/16"x2-1/4")		4
3	SHORT BOLT (5/16"x1-3/4")		2
4	SPRING WASHER (5/16")		10
5	FLAT WASHER (5/16"x3/4)		10
6	ALLEN KEY (M5x2-1/2")		1




STEP 1:

Place the chair back (A) on a soft and clean surface.

Assemble the cushion seat (B) with the chair back (A) by using Allen Key (6) with hardware 3,4, and 5.

****Attention: DO NOT TIGHTEN THE BOLTS.**



MADE IN VIETNAM

Assembly Instruction

Collection: CARISSA


Item No: D422-20

CARISSA DINING CHAIR (2 PER CARTON)

STEP 2:

Assemble the cushion seat (B) with the back legs of the chair back (A) by using Allen Key (6) with hardware 1, 4, and 5.


****Attention: DO NOT TIGHTEN THE BOLTS.**



STEP 3:

Assemble the legs (C) with the Cushion Seat (B) by using Allen Key (6) with hardware 2, 4, and 5.

****Attention: DO NOT TIGHTEN THE BOLTS.**





Assembly Instruction

Collection: CARISSA


Item No: D422-20

CARISSA DINING CHAIR (2 PER CARTON)

STEP 4:

To level the chair, turn the chair right side up on a flat surface and tighten the bolts with Allen Key (6).

****Attention: DO NOT OVERTIGHTEN THE BOLTS.**



MADE IN VIETNAM