

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

193820(B1&B2)
Dining Table

ITEM: **193820(B1&B2)**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	TOP		1PC
B	MOUNTING PLATE (PRE-ATTACHED TO TOP)		1PC

B2 (BOX 2)

C	LEG (L) WITH LABEL "1"		1PC
D	LEG (R) WITH LABEL "1"		1PC
E	LEG (L) WITH LABEL "2"		1PC
F	LEG (R) WITH LABEL "2"		1PC

ITEM: 193820(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 193820 (B1)

1	ALLEN WRENCH (M4 X 60MM - RBW)		1PC
2	BOLT (M6 X 30MM - RBW)		4PCS
3	LOCK WASHER (M6 X 30MM - RBW)		4PCS
4	FLAT WASHER (M6 X 30MM - RBW)		4PCS
5	WOOD DOWEL (M8 X 30MM)		14PCS
6	LEVELER		8PCS


ITEM: 193820(B1&B2)



ASSEMBLY INSTRUCTIONS

STEP 1


Attention! Please remove part B and all hardware from TOP (A), using ALLEN WRENCH (1) and keep for STEP 8 and STEP 9.



STEP 2



STEP 3




ITEM: **193820(B1&B2)**


ASSEMBLY INSTRUCTIONS

STEP 4


COASTER
FINE FURNITURE



STEP 5



STEP 6




ITEM: 193820(B1&B2)


ASSEMBLY INSTRUCTIONS



STEP 7




STEP 8



STEP 9

Attention! Use hardware from STEP 1 for this STEP.




***BOTTOM VIEW**

ITEM: **193820(B1&B2)**

ASSEMBLY INSTRUCTIONS




STEP 10




STEP 11

COMPLETE



ITEM: **193820(B1&B2)**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

193822
Side Chair

ITEM:193822



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES



PARTS IDENTIFICATION

A SEAT AND BACK





1PC

B FRONT LEG



2PCS

C BACK LEG



2PCS

HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 X 60MM - RBW)



1PC

2 LONG BOLT
(M6 X 60MM - RBW)



8PCS

3 LOCK WASHER
(M6 X 13MM - RBW)



8PCS

4 FLAT WASHER
(M6 X 19MM - RBW)




8PCS


ITEM: **193822**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




*BOTTOM VIEW

STEP 3 COMPLETE



ITEM: **193822**

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$